

Remington Confidential

- While maintaining a firm hold on the bolt handle, gently, and slowly ease the bolt forward to the full forward position and then rotate down being sure that the action locks fully.
- Holding the firearm in a horizontal and level position, and pointing the firearm in a safe direction, pull the trigger until the firing pin releases.
- Carefully open the action and remove the crusher holder, being careful not to drop the copper crusher.
- Leave the crusher in the holder and place under the dial indicator.
- Move the crusher holder so that the point of the dial indicator finds the deepest portion of the firing pin indent.
- Record the dial indicator reading to the nearest .001”.
- Repeat procedure two more times and record the dial indicator readings using a new copper crusher for each trial.
- Each firearm sample should have three readings that will be averaged.
- Record all three readings for the data file.

Data Required:

- Rifle serial number
- Each of the three trial indents
- The calculated average indent by rifle.

TLW0010E - Measure Sear/Trigger Engagement and Sear Lift:

The Sear/Trigger Engagement will be measured. The amount of engagement must be measured between .020” and .025” measured with the bolt in the fully closed and locked position.

Method for measuring Sear/Trigger Engagement:

- The 30” Optical comparator will be used to measure the engagement at 50X magnification.
- With the barreled action held firmly in position, the barreled action will be aligned such that the action is held perpendicular to the lens in both the horizontal and vertical planes.
- With action closed and locked, the safety in the “fire” position, measure the amount of overlap between the sear and the trigger.

Method for measuring Sear Lift:

- Remove the bolt from the action.