

Cleaning Frequency

1. Before and after long term storage.
2. When the rifle has been subjected to adverse conditions such as shooting in the rain, snow, sleet or saltwater areas.
3. When the rifle is exposed to dirty conditions such as lying on the ground outdoors, being dropped in mud, etc.

NOTE: While the Model 700™ and Model Seven™ Stainless Synthetic Rifle have been designed and manufactured to provide improved corrosion protection, only proper care will keep your firearm in good operating condition and maintain its appearance. After extensive use, the protective coating on plated parts may be worn sufficiently to reduce corrosion protection. Such worn parts should be replaced to assure the integrity of the corrosion protection.

WARNING: After each use, follow the lubrication and maintenance direction in this instruction book. If the firearm is immersed in water, it must be more fully cleaned and lubricated as soon as possible to rid it of salt-water immersion. First flush all parts with fresh water then dry. If you notice cracks in the finish of the firearm, does not function properly, have it inspected by a REMINGTON® authorized dealer before further use. Failure to follow this warning may lead to firearm malfunction, which could result in personal injury or death.

Instructions for Cleaning the Bolt Assembly

TO DISASSEMBLE THE BOLT ASSEMBLY:

1. Remove the bolt assembly from the firearm. See instructions on page 9.
2. *For Models 700 and Seven:* Put the firing pin on the firing pin head over a metal edge. Pull the bolt assembly away from the firing pin. Pull a coin into the slot near the back edge of the firing pin head. See Picture 16. *For Model 710™:* Rotate bolt plug clockwise 180° of a turn and remove the firing pin/bolt plug assembly. **Note:** When the firing pin is released from the bolt assembly, the bolt head pin can be removed and the bolt head and bolt body can be separated. Skip step 3 and go directly to step 4 and 5.
3. Hold the bolt assembly and turn the bolt plug counter clockwise until the firing pin assembly can be removed from the bolt assembly.

CAUTION: Clean the firing pin assembly carefully.

4. Clean all parts with gun cleaning solvent. Dry with a clean cloth.
5. Apply a thin coat of HEMO.

TO ASSEMBLE:

1. *For Models 700 and Seven:* Put the firing pin assembly into the rear of the bolt assembly.
2. *For Model 710:* Assemble the bolt head to the bolt body and insert the bolt head pin. If assembled correctly, the bolt assembly will be 180 degrees from the ejector, as viewed from the front.
3. *For Models 700 and Seven:* Push the bolt plug into the bolt assembly with your hand.
4. *For Models 700 and Seven:* Pull the coin from the slot in the firing pin head.
5. *For Model 710:* Press the bolt plug into the bolt body and rotate counter clockwise until the firing pin head engages the notch in the bolt body. See Picture 18.
6. *For Models 700 and Seven:* Turn the bolt plug until the firing pin head goes into the small notch on the rear rim of the bolt. The bolt is now cocked. See Picture 19.

NOTE: *For Models 700 and Seven:* The bolt must be cocked to be assembled into the rifle.

For Model 710: If bolt assembly does not align with receiver, disassemble the bolt assembly, rotate the bolt head 180 degrees and reassemble.

5. *For Models 700 and Seven:* Assemble the bolt assembly into the rifle. See instructions on page 9.

