

Read the 10 Commandments of Safety before beginning.

***To remove the bolt assembly and clean:***

1. Point the firearm in a safe direction.
2. Put the safety switch in the "S" position.
3. Do not touch the trigger while moving the safety switch.
4. Raise the bolt handle
5. Rotate bolt stop counter-clockwise to vertical position
6. Pull the bolt handle all the way back.
7. Slide the bolt from the firearm.
8. Remove the bolt assembly from the firearm.
9. Check the chamber to make sure it is empty.
10. Rotate bolt plug clockwise 1/8" of a turn and remove the firing pin/bolt plug assembly. Note: When the firing pin is removed from the bolt assembly, the bolt head pin can be removed and the bolt head and bolt body can be separated.
11. Hold the bolt assembly and turn the bolt plug counter clockwise until the firing pin assembly can be removed from the bolt assembly. Caution: Clean the firing pin assembly as a unit. Do not disassemble firing pin assembly
12. Clean all parts with gun cleaning solvent. Dry with a clean cloth.
13. Apply a thin coat of Rem-Oil.

***To clean the barrel:***

**Warning!** Check the chamber and magazine to make sure there are no cartridges in the firearm.

1. Use the equipment provided in a good cleaning kit. For recommendations, see your Remington Authorized gunsmith.
2. Remove the bolt assembly.
3. Select the correct caliber cleaning brush and attach the brush to the cleaning rod.
4. Put the cleaning brush into the gun cleaning solvent.

**Note:** Barrel should lay horizontally with the ejection port facing down during cleaning. Always clean the barrel from the chamber end to the muzzle.

5. Push the cleaning brush through the barrel several times.
6. Remove brush from rod, attach tip with patch, and push through the bore.
7. Repeat several times, using a new cleaning patch each time, until the patch is not dirty.
8. Push a clean patch saturated with Rem Oil through the barrel.
9. Push a clean dry patch through the barrel to remove excess lubricant.
10. Apply a thin coat of Rem Oil to the outside of the barrel with a soft clean cloth.
11. After cleaning the barrel, clean the receiver and the trigger assembly.