

3/12/82

M/700 WAREHOUSE

CHECK FOR NEW SAFE ARM

NO BOLT LOCK

1. Check all guns produced from February 26th to March 12th - Label marked AC.
2. Open box.
3. Remove action and bolt assembly from box.
4. Check for live ammo, then insert bolt assembly in action.
5. Close bolt, put safe on, then try to open bolt. BOLT MUST OPEN.
6. Check instruction folder in box - on back side of folder - check for Rev. 182.
7. If guns and instruction folders in Step 5 & 6 are correct - proceed to Step 8.  
If guns and instruction folders are incorrect, STOP - Review with J. J. Burns or G. J. Hill.
8. Remove bolt assembly and repack gun and insure correct owners manual is repacked in box.
9. Retape box - Mark "C" on label.

RESPONSIBILITIES

- Production - Check all required guns.
- Planning - Make all guns available to production from 2/26 - 3/12.
- P E & C - Audit guns repacked by production, and instruct production on procedure for incorrectly packed guns.

GJH/cac