BARBER - RE 0005859

- 1. Measure safety on and off forces on 8 Model 770 fire controls with the new trigger block safety. Take 3 readings of safety on forces and 3 readings of safety off forces and average each one.
- 2. Replace the safety detent spring with one made from .038" wire and repeat the measurements done in step 1.
- 3. Replace the safety detent spring with one made from .035" wire and repeat the measurements done in step 1.