

$\begin{array}{r} .4925 \\ + .0025 \\ \hline .4950 \\ + .0025 \\ \hline .0500 \end{array}$

Large Hole $\begin{array}{r} .3317 \\ + .0500 \\ \hline .3817 \pm .0025 \end{array}$

$\begin{array}{r} .2835 \\ + .2855 \\ \hline .5690 \end{array}$

Small Hole $\begin{array}{r} .2813 \\ + .0007 \\ \hline .2820 \end{array}$

$.2845 \pm .001$

$\begin{array}{r} .2813 \\ + .0007 \\ \hline .2820 \end{array}$

$\begin{array}{r} .3817 \\ + .0025 \\ \hline .3842 \end{array} / .3792$

$\begin{array}{r} .2820 \\ + .0007 \\ \hline .2827 \end{array}$

$\begin{array}{r} .2820 \\ + .0007 \\ \hline .2827 \end{array}$

$\begin{array}{r} .2812 \\ + .0007 \\ \hline .2819 \end{array}$

$\begin{array}{r} .2835 \\ + .0015 \\ \hline .2850 \end{array}$

$\begin{array}{r} .2855 \\ + .0050 \\ \hline .2905 \end{array}$

$\begin{array}{r} .2508 \\ + .0015 \\ \hline .2523 \end{array}$

$\begin{array}{r} .2493 \\ + .0050 \\ \hline .2543 \end{array}$

Norm. 2812

.2805
 .0007 (-)

Norm. 2820
.2812
 .0008 (+)

Pin

Norm. 2500

.0007
 .2493

Norm 2500

.0008
 .2508

Pin

Norm. 2813
.2812 (+)
 .0001

Norm. 2833
.2812 (+)
 .0021

None

.2500
~~.0001~~
.2501

.2500
.0021
 .2521

None

.3317
.0025
 .3292

.3317
.0025
 .3342