

$$\begin{array}{r}
 .4905 \quad \pm .0025 \\
 .4425 \quad \pm .0025 \\
 \hline
 .0500
 \end{array}$$

Large Hole

$$\begin{array}{r}
 .3317 \\
 .0500 \\
 \hline
 .3817 \quad \pm .0025
 \end{array}$$

$$\begin{array}{r}
 .2835 \\
 .2855 \\
 \hline
 .5690
 \end{array}$$

Small Hole

$$\begin{array}{r}
 \cancel{.2845} \quad \pm .001 \\
 .2813 \\
 \hline
 \cancel{.0030} \quad \pm .001 \\
 \hline
 .2783 \\
 \hline
 .2783 \quad \pm .001
 \end{array}$$

$$\begin{array}{r}
 .3817 \\
 .0025 \\
 \hline
 .3842 / .3792
 \end{array}$$

$$\begin{array}{r}
 .2820 \\
 .2813 \\
 \hline
 +.0007 \\
 .2501 \\
 \hline
 .2508
 \end{array}$$

$$\begin{array}{r}
 .2820 \\
 .28125 \\
 \hline
 +.00075
 \end{array}$$

$$\begin{array}{r}
 .2812 \\
 .2805 \\
 \hline
 (-).0007
 \end{array}$$

$$\begin{array}{r}
 .2885 \\
 .2820 \\
 \hline
 .0065
 \end{array}$$

$$\begin{array}{r}
 \cancel{.2807} \\
 \cancel{.2493} \\
 .2855 \\
 .2805 \\
 \hline
 .0050
 \end{array}$$

$$\begin{array}{r}
 .2508 \\
 .0015 \\
 \hline
 .2523
 \end{array}$$

$$\begin{array}{r}
 .0050 \\
 .2493 \\
 \hline
 .2543
 \end{array}$$

Norm. 2812

.2805
.0007 (-)

.2820
Norm. 2812
.0008 (+)

Pin

Norm. 2500

.0007
.2493

Norm 2500

.0008
.2508

Pin

.2813
Norm. 2812 (+)
.0001

.2833
Norm. 2812 (+)
.0021

None

.2500
~~.0001~~
.2501

.2500
.0021
.2521

None

.3317
.0025
.3292

.3317
.0025
.3342