


7. Put the safety switch into the "off" position.
8. Now pull the trigger.
9. Open the action and remove the crusher holder. To do this, tip the gun on its side with the palm of your hand under the port. Push the piston toward the crusher holder and it will fall to your hand. (Fig # 6-8)

Fig No. 6-8

10. Remove the copper crusher cylinder from the crusher holder and place it (piston end down) onto the platform of the drill rod. Carefully lower the styrene into the firing pin indent. Gently move the cylinder around until the styrene just reaches the deepest part of the indent Fig # 6-9

Fig No. 6-9