

MAGAZINE EXTENSION KIT

CONVERTS 5-SHOT M870 POLICE TO 7 OR 8-SHOT CAPACITY

NOTE: THE MAGAZINE EXTENSION IS PACKAGED FULLY ASSEMBLED.

BEFORE ASSEMBLING:

1. REMOVE THE MAGAZINE EXTENSION SWIVEL ASSEM. SCREW SCREW.
2. SLIDE THE MAGAZINE EXTENSION SWIVEL ASSEM. FROM THE MAGAZINE TUBE EXTENSION ASSEM.
3. UNSCREW AND REMOVE THE MAGAZINE TUBE COUPLING.

TO ASSEMBLE THE MAGAZINE EXTENSION KIT:

1. ENGAGE THE SAFETY SWITCH. (RED BAND WILL NOT SHOW)
2. CHECK THE CHAMBER AND THE MAGAZINE TO MAKE SURE THERE ARE NO SHELLS IN THE FIREARM.
3. UNSCREW AND REMOVE THE MAGAZINE CAP.
4. PUT A SCREWDRIVER INTO THE OPEN END OF THE MAGAZINE TUBE. MOVE THE TIP UNDER THE RIM OF THE MAGAZINE SPRING RETAINER.
5. PLACE YOU HAND OVER THE END OF THE MAGAZINE TUBE.
6. UNSE THE SCREWDRIVER, PRY UP AND REMOVE THE MAGAZINE SPRING RETAINER. (WARNING: USE EXTREME CARE WHEN REMOVING THE MAGAZINE SPRING RETAINER AS THE RETAINER IS UNDER TENSION FROM THE MAGAZINE SPRING.)
7. REMOVE THE MAGAZINE SPRING. DO NOT REMOVE THE MAGAZINE FOLLOWER.
8. SCREW THE MAGAZINE TUBE COUPLING TIGHTLY ONTO THE MAGAZINE TUBE.
9. INSERT THE MAGAZINE SPRING FROM THE KIT INTO THE MAGAZINE TUBE.
10. SCREW THE MAGAZINE TUBE EXTENSION INTO THE MAGAZINE TUBE COUPLING. (NOTE: DO NOT TIGHTEN EXCESSIVELY AS THIS MAY CAUSE THE SHELLS TO BIND IN THE TUBE.)
11. PLACE THE MAGAZINE EXTENSION SWIVEL ASSEM. ON THE MAGAZINE TUBE EXTENSION AND SLIDE REARWARD.
12. ALIGN THE SCREW HOLE IN THE MAGAZINE EXTENSION SWIVEL ASSEM. WITH THE DETENT IN THE MAGAZINE TUBE EXTENSION ASSEMBLY