
The bolt stop is located on the left rear side of the receiver and must be pulled out to remove the bolt. However, this does not have to be touched on bolt re-insertion since it is cammed out of the way by the bolt. (Photo #2)



Ţ