CLEANING INSTRUCTIONS

How to baben

PARTS AND SER

THE BARREL

The inside of the berrel must be clean and free of obstructions.

- TO CHECK THE INSIDE OF THE BARREL: ١.
- Point the firearm in a safe direction.
 Put the safety switch in the "F" position.
 Raise the bolt handle.
- Put the safety switch in the "S" position.
- Pull the bolt handle all the way back. Remove any ammunition from the chamber or magazine. See page 8.
- Remove the bolt. See page 5.
- Look through the inside of the barrel from the chamber and to the muzzle. See planure 1.
- TO REMOVE OBJECT FROM INSIDE THE BARREL: н
 - Use the correct size cleaning rod.
- Ose the correct size dearing rod.
 Push the cleaning rod from the chamber end all the way through the barrel, until the rod cornes out the muzzle.
 If an object cannot be assily pushed out of the barrel with a cleaning rod, return the firearm to the factory or a REMINGTON RECOMMENDED GUNSMITH.



NEVER try to remove an object from the barrel STOP by loading snother cartridge and firing.

TO CLEAN THE BARREL FOLLOW INSTRUCTIONS SHOWN ON PAGE 11.

Before loading the firearm make sure the inside of the barrel is free of dirt, or other objects.