

Trigger Assy

Pull trigger would not
fire changing position of
gun causes it to fire