

Model Seven

Discussion Thread

Response (Howerton) 3/31/2008 6:39:39 AM

Remington Models Seven & 710

Remington Sportsman 78, Model Seven and 710 bolt-action rifles are not included in the safety modification program. These rifles have been manufactured since 1982 and do not have a bolt-lock mechanism. As a result these rifles may be loaded or unloaded with the safety in the S or On Safe position.

Nevertheless, as with any firearm, special care must be taken during the loading and unloading process. Always keep the muzzle pointed in a safe direction. Always unload your rifle when not actually in use. Keep the safety in the S or On Safe position at all times until you are ready to shoot. Every firearm should be unloaded as soon as you are finished shooting - before taking it into your car, camp or house. Remington wants you to enjoy the shooting sports - safely!

Should you desire service on any of your Remington firearms please feel free to call us on our toll free service line 1-800-243-9700 or visit the Remington Authorized Repair Center nearest you.

Customer (Oke Johnson) 3/28/2008 10:13:00 AM

I have a Model Seven that I purchased In June of 2005. On three separate occasions it has discharged when I moved the safety to the fire position. In all cases the rifle was lying on it's side when it discharged. Fortunately the muzzle was pointed towards the ground so no injuries occurred. However, I did miss opportunities on three whitetails. I was able to replicate the discharge on several occasions, but only by putting an empty casing in the chamber.

Could you let me know if you have seen this before and also how I can get it corrected.

Thanks,  
Oke Johnson