

*Copied & what was sent to Customer 11/14/89*

# THE BOLT ASSI



TO INSTALL THI

5

*Post it paper  
with arrows  
Policy*


# THE BARREL

The  
I.  
1.  
2.  
3.  
4.  
5.  
6.  
7.

# THE TRIGGER ASSEMBLY

Pulling the trigger fires the firearm.

The trigger is adjusted at the factory. All adjustments to the trigger must be made by the factory or a REMINGTON RECOMMENDED GUNSMITH.



Never remove the trigger mechanism, or make adjustments to the trigger or trigger assembly.



NEVER put your finger on the trigger unless you are going to fire the firearm.

II  
1.  
2.  
3.

III

Befo  
free  
V