


Magazine

A latch in the front of the separate trigger guard holds the hinged floor plate into position. The trigger guard and hinge also secure the magazine box to the receiver. The magazine spring is the "W" type which slides into a "T" slot in the bottom of the follower while the opposite end of the spring attaches to the floor plate in this same way. (Photo #9)



This system is similar to that used in our BDL grade M/700's.