PRESALE R 0110670

R2511658

SERVICE POLICY (Cont'd)

PARTS:

1. All parts orders should be sent to: Sturm, Ruger & Co., Inc., Product Service Dept., Newport, New Hampshire 03773

2. Please send remittance with order for parts. Because of handling costs, we cannot accept orders for parts for less than \$1.00.

3. Order parts by both name and number.

FIREARMS:

1. Ruger Model 77 Rifles returned for service should be sent to: Sturm, Ruger & Co., Inc., Product Service Dept., Newport, New Hampshire 03773.

2. Rifles shipped to factory should be sent prepaid. We will not accept collect shipments.

3. For best repair service, always enclose letter furnishing serial number and Model of rifle. Also, state nature of trouble experienced or of work desired. (Merely stating "defective" or "repair" is inadequate information.) Please enclose copies of any previous correspondence.

4. Work performed will bear a net minimum labor charge of \$5.00. The charge for re-bluing is \$15.00, which includes labor.

5. Federal regulations must be complied with when shipping any firearm. In certain states and under certain regulations, it may be impossible for us to return a repaired firearm to an individual. It is therefore most strongly recommended that all firearms sent to us for repair, be sent through a federally licensed dealer!

WARNING

Check chamber before shipping firearm. If firearms are sent to us in a loaded condition, we must notify Federal authorities.

Please do NOT send to our factory your scope or rifle case with the firearm being sent to us for repair.

RETAIL PARTS LIST

Part No.	Description	Price
	*Barrel (only) (specify caliber)	\$45.00
D-3 ***D-66	Barrel Band	5.75
***D-86B	Barrel Band Screw (not illus.)	.50
D-10	*Bolt (only)	25.00
D-10 D-35	Bolt Lock	1.25
D-53	Bolt Stop	6.00
D-33 D-56	Bolt Stop Plunger	.50 .25
D-50 D-57	Boit Stop Plunger Spring	.25
D-59	Bolt Stop Plunger Spring Retaining Pin	.25
D-54	Bolt Stop Screw Stud	.50
D-55	Bolt Stop Stud Bushing .	.25
D-8	Ejector	1.00
D-41	Elector Retaining Pin	.25
D-9'	Ejector Spring	.25
**D-14	Extractor	7.00
**D-15	Extractor Band	2.00
*D-11	Firing Pin (assembly only)	10.00
++D-5	Floor Plate	4.00
D-7	Floor Plate Hinge	3.00
D-6	Floor Plate Pivot Pin	.25
***B-51	Forend Escutcheon (2 req'd) (not illus.)	.25 (each)
**D-27	Magazine Box	3.00
D-127	Magazine Box Assy. (.220 Swift only)	5.00
P. 10.	,	

**D_30	Magnzine Follower (stainless steel)	6.00	
D-30	Magazine Latel	2.00	
D-31	Magazine Latch	2.00	
**D-30 D-31 D-40 D-32 **D-33 C-97 C-107	Magazine Latch Pin	.25 .25	
D-32	Magazine Farcu Shring	2.23	
**0-33	Magazine Spring	2.00	
C-97	Pistol Grip Cap	1.50	
C-107 C-96	Pistol Grip Cap Medallion	.50	
C-96	Pistol Grip Cap Screw	.25	
	Magazine Latch Pin Magazine Latch Spring Magazine Spring Pistol Grip Cap Pistol Grip Cap Medallion Pistol Grip Cap Screw Receiver not Receiver, Mounting Screw (front) Receiver, Mounting Screw (center) Receiver, Mounting Screw (rear) Recoil Pad	offered	
D-46 D-47 D-48 S-63	Receiver, Mounting Screw (front)	1.00	
Ď.47	Receiver Mounting Screw (center)	.50	
D.48	Receiver Mounting Screw (rear)	.25	
6.42	Recoil Pad	5.00	
3-03	Recoil Pad Screws (2)	.50	
th 20			
D-38 D-39	Safety Button	3.00	
D-39	Safetý Link Safety Shaft Assembly	.50	
D-58 D-37 D-37	Safely Shaft Assembly	3.00	
D-37	Safety Spring	.25	
	Sear	4.00	
D-42 D-24 D-71	Sear Pivot Pin	.50	
D. 24	Sent Spring	.25	
D-24		15.00	(male
D-71 D-71H D-73 D-76 D-68 D-69 **D-65 D-70 D-67 D-77 **D-60 D-61 D-62 D-81A	Scope Ring Assembly (STD.) Scope Ring Assembly (high) Scope Ring Clamp Scope Ring Nut Scope Ring Screw Sight (front)—Plunger Sight (front)—Plunger Spring Sight Base (front) Sight Base (front) Sight Base (front)—Set Screw Sight Blade (front) Sight (rear) Folding, Complete Sight (rear) Base Only Sight Base (rear)—Center Screw Sight Base (rear)—Rear Screw Williams Cib Lock (sight clamp rear)		
D-7111	Scope King Assembly (nigh)	15.00	
D-74	Scope Ring Clamp	2.00	
D-73	Scope Ring Nut	1.00	(esc)
D-76	Scope Ring Screw	.25	(escl
D-68	Sight (front)-Plunger	.25	•
D-69	Sight (front)-Plunger Spring	.25	
**D-65	Sight Rase (front)	8.00	
D-70	Sight Base (front)_Set Screw	.25	
h-70	Sight Blade (front)	2.00	
D-07	Sight from Folding Complete	3.00	
D-11	Signt (rear) Polating, Complete	5.00 5.00	
**D-00	Signt (rear) Daso Only	3.00	
ħ-01	Sight Base (rear)—Center Screw	.50	
D-62	Sight Base (rear)—Rear Screw	.50	
D-83A	Williams Gib Lock (sight clamp rear)	.50	
D-83B	Screw For Part #D-83A	25	
D-86	Sling Swivel Front Screw With Nut	.50	
Ď.ŘŽ	Sight Base (rear)—Center Screw Sight Base (rear)—Rear Screw Williams Gib Lock (sight clamp rear) Screw For Part #D-83A Sling Swivel Front Screw With Nut Sling Swivel Rear Mounting Stud Stock (complete with pad & checkered) Stock Cross Bolt tnot illus.) Stock Cross Bolt tnot illus.) Stock Reinforcement Assy. (not illus.) Stock Reinforcement Screw (not illus.) Trigger Guard Trigger Trigger Adjustment Screw (engagement)	.50	
**0.4	Stock (complete with ned & checkered)	50.00	
eeeb inc	Ctack Cross Ball trast illus	1.00	
***D-100	Stock Cross Bull Blot (max.)		
***D-10/	Stock Closs Bolt Mit Just line")	.35	
***D-104	Stock Keinforcement Assy. (not illus.)	6.00	
***D-75	Stock Reinforcement Screw (not illus.)	35	
D-2	Trigger Guard	8.00	
D-20	Trigger	5.00	
D-22	Trigger Adjustment Screw (engagement)	1.00	
Ď-43	Tripper Adjustment Screw (weight of pull)	.25	
D-22 D-43 D-45 D-44	Trigger Adustment Screw (weight of pull) Trigger Adustment Screw (over travel)	.25	
ň	Trigger Adjustment Set Screw (over travel)	.25	
D-44 D-25 D-26	Trioner Housing	4.00	
D-23	Trigger Housing	.25	
D-70	Trigger Housing Cross Pin Trigger Pivot Pin	.25	
D-21	Trigger Livor Liu	.23	
D-49	Trigger Kelurn Spring	.25	
D-51	Trigger Return Spring Seat	.50	
	- -		
*Must he f	lited at the factory		

^{*}Must be fitted at the factory **Order by Part No. and Caliber

^{***}Required for .458 Caliber rifles only