

when I reassembled the gun, I used the torque specifications in the manual. Using what I thought were the proper specifications, I split the rear synthetic trigger housing boss.

I was very discouraged. Well we went, the rifle worked great and my daughter had a successful and memorable hunt. Now I need a new safety lever and a new trigger housing. What do I need to do?