

remington bolt

Discussion Thread

Response (Nicole)  
Dear Brady,

2/9/2004 11:46:17 AM

Welcome to Remington Country and thank you for your inquiry. The bolt is cocked when the bolt handle is lifted this is an industry design and is not unsafe due to the fact the firing pin does not disengage the sear and disconnecter until they are separated.

Again, we thank you and appreciate your support of Remington products.

Customer (Brady Dunlap)  
Remington,

2/2/2004 9:18:02 PM

At what point in the cycling of your bolt action does the firing pin cock. In most bolts it seems to cock when the bolt handle is first lifted. However this would mean the bolt is cocked while chambering the next round, which seems unsafe. Thank you for your time.

Brady Dunlap