

Employee Technical Test 597

Must remove the take down screws, stock assembly, and then push the trigger assembly to the right. You then can pull the trigger assembly away from the receiver. Sometimes the bolt will hold the trigger assembly back and you must release/close the bolt.

10. List the all the parts that come with part number F305050

Bolt, Firing pin, firing pin spring, F/P retaining pin, extractor, extractor plunger, extractor spring, bolt handle spring, and bolt handle rivet.

11. What is the function of the hole partially drilled through the bottom of the bolt?

This hole has no function for the proper operation of the bolt. It used in the manufacturing process.