Summary	Total Test + Pi	roof Failures tal Rejected:									Test Date:					
		Reject Rate:	14.48													totals
		Shot:	99	235	92	68	79	26		113		3		l		715
	Proof	Rejected: Percent:	11 11.1	2 0.9	10 10.9	1 1.5	0 0.0	6 23.1	1	0 0.0	0	0 0.0	0	0	0	31 4.3
		Shot:	174	269	51	39	4	75	65	124			44		8	853
	Test	Rejected: Percent:	5 2.9	5 1.9	9 17.6	2 5.1	0 0.0	7 9.3	27 41.5	40 32.3	0	0	0 0.0	0	0 0.0	98 11.1
		Shot:	76	169	51	61	20	9	38	3		Ι	T	I		427
	Target	Rejected: Percent:	0 0.0	0 0.0	1 2.0	0 0.0	0 0.0	0 0.0	1 2.6	0 0.0	0	0	0	0	0	2 0.5
CODE	MALFUNCTION II		700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
AB	Action binds									2						2
BABS	Bulge at body shoulder								2							2
BAC	Burr at chamber															
ВВМА	BBL-to-bolt misalignment															
BB	Bolt binds/catches		1					1								3
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector ou	t of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazin	е														
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full ma	agazine														
CD	Case dented															
СН	Closes hard		2													5
CLM	Can't laod magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action	bar														
DBB	Doesn't blow back															
DCS	Double click in safety switch	h														
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject				1											1
													1			

DEL

Doesn't eject live round

DFB	Doesn't feed back	1									
	Doesn't feed up										
	Doesn't lock open (after last shell)										
\vdash	Doesn't lock-up							20			20
	Dead safe							20			20
	Doesn't extract										
	Doesn't extract live round			1	2		2				ş
	Extractor drops shell			1	2		2				. j
	Ejector sticks back										
	Empty shell catches receiver	-									
\vdash	Extractor stems shell										
FA	Fires automatically										
	Follower binds										
	Fails to connect										
	Fore-end cracked or broken										
	Follows-down							1			1
	Fails to fire										
	Flat firing pin										
	Fires on safe										
	Firing pin hits bbl										
FPHI	Firing pin hits inside rim										
FPO	Floor plate opens	1		1							5
FPOH	Floor plate opens hard										
FSR	Fires when safe is released										
FT	Follower tips										
GCSO	Gas cyl shot off										
HBL	Heavy bolt lift		1	1							2
HMSC	Heading mismatch-steps on case										
HPA	High pressure ammo										
HUR	Hard under rail			1							1
JCS	Jumps cartridge										
JM	Jumps magazine					5					5
JO	Jars off										
LB	Light blow										
МАН	Magazine assembles hard										
	Magazine capacity wrong										
	Misfires (ammo)										
мғор	Magazine follower out of position										
	Magazine loose										
	Magazine loads hard										
	Magazine removes hard							1			1
ОН	Opens hard										
$\overline{}$	Over-rides	1		1				4			ŝ
	Pulls hard	·						*			

PSI	Proof stamp illegible				l				I			ı	
	Proof stamp missing												
	Rings and bulges on case												
	(Action) release doesn't work												
	Rings in chamber												
	Ring in sholder						12						12
	Rim srem												
	Stems bottom chambers						1						1
	Stems bbl extension												
	Stock cracked or broken												
SCX	Shell catches												
SHI	Short indent												
SI	Stems incline												
SIC	Stems in chamber												
	shaves lead												
SLC	Stems left side of chamber						1	12					13
SMOC	Stretch marks on case												
SOR	Stem over-ride						9						9
SP	Stems port												
SR	Shoulder rough												
SRC	Stems right side of chamber												
SRIC	Specific rings in chamber												
SSOC	Surface scratches on case												
STC	Stems top chamber												
SWE	Safety switch works too easily												
SWH	Safety switch works too hard												
sww	Safety ewitxh won't work												
TD	Tips down												
TU	Tips up												
TWP	Trigger won't pull												
TWR	Trigger won't retract												
UNCN-T	Uncoded												
XH	Extracts hard		4	3		1							8
н	High												
	Low			1									
	Left			İ									
	Right												
	Doesn't Group			1			1						ž
	Front sight tipped												
	Rear sight tipped												
	Rear sight base raised												
	Front sight raised												
	Front sight loose												
. 512	ront signt 10036	I d		I	l	l			l		l	l	

RSTL	Rear sight loose										
MGPT-G	Missing parts at target										
UNCN-G	Uncoded nonconformity at target										
AI-P	Assembly incompleye at proof										
BBB	Barrel bracket cracked or broken at proof										
BC-P	Blows cases at proof										
BEB-P	Barrel extension broken at proof										
BLP-P	Blanked primer at proof										
BLSO-P	Barrel lug shot off at proof										
BP-P	Blown primer at proof										
BS-P	Barrel split at proof										
DLOS-P	Doesn't lock over shells at proof										
ESB-P	Ejector sticks back at proof										
FCB-P	Fore-end cracked at proof										
FESO-P	Fore-end shot off at proof										
FF-P	Fails to fire at proof										
GCSO-P	Gas cylinder shot off at proof										
MSI-P	Magnaflux stamp illegible on bbl										
MSM-P	Magnaflux stamp missing on bbl					1					1
PP-P	Pierced primer at proof	10	1	10		5					26
SCB-P	Stock cracked or broken at proof										
UNCM-P	Uncoded proof malfunctions	1	1		1		1				4

Summary	Total Test + Proof		989 107								Test Date:					
	Overall Rej	Rejected: ect Rate:	10.82													totals
		Shot:	399	4	117	26		5	1	22			26	20	29	643
	Proof	Rejected: Percent:	0 0.0	0 0.0	1 0.9	0 0.0	0	0 0.0	0 0.0	0 0.0	0	0	0 0.0	0 0.0	1 3.4	2 0.3
		Shot:	392	101	99	26	280			48		12			29	987
	Test	Rejected: Percent:	57 14.5	11 10.9	7 7.1	0 0.0	8 2.9	0	0	6 12.5	0	3 25.0	0	0	13 44.8	105 10.6
		Shot:	35	12	9	26		Ι		1-1-1		I		1	I	82
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	0	0	0	0 0.0
CODE	MALFUNCTION INDE.	х	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches		2	4	1		1									8
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
ВС	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of p	osition														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magazi	ine	28													28
CD	Case dented															
СН	Closes hard		1	2	1											4
CLM	Can't laod magazine															
СО	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back									2						2
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject									1						Ť
DEL	Doesn't eject live round															

	T	1		1			1	ı	1		ı		
DFB	Doesn't feed back												
DFU	Doesn't feed up											6	ફ
DLO	Doesn't lock open (after last shell)												
DLU	Doesn't lock-up											2	2
DS	Dead safe	1			2								3
DX	Doesn't extract	1		2			2						5
DXL	Doesn't extract live round												ĺ
EDS	Extractor drops shell	5		1								3	9
ESB	Ejector sticks back												ĺ
ESCR	Empty shell catches receiver												ĺ
ESS	Extractor stems shell												
FA	Fires automatically												ĺ
FB	Follower binds												
FC	Fails to connect											2	2
FCB	Fore-end cracked or broken												
FD	Follows-down												
FF	Fails to fire				3								3
FFP	Flat firing pin												
FOS	Fires on safe												
FPHB	Firing pin hits bbl												
FPHI	Firing pin hits inside rim												
FPO	Floor plate opens												
FPOH	Floor plate opens hard												
FSR	Fires when safe is released												
FT	Follower tips	2											5
GCSO	Gas cyl shot off												
HBL	Heavy bolt lift	2	1	1									4
HMSC	Heading mismatch-steps on case												
HPA	High pressure ammo												
HUR	Hard under rail		1										1
JCS	Jumps cartridge												
JM	Jumps magazine	1											1
JO	Jars off												
LB	Light blow												
МАН	Magazine assembles hard												
MCW	Magazine capacity wrong												
MFA	Misfires (ammo)												
MFOP	Magazine follower out of position												
ML	Magazine loose												
MLH	Magazine loads hard												
MRH	Magazine removes hard												
ОН	Opens hard												
OR	Over-rides	13											13
PH	Pulls hard												
	•	•	•	•			•	•		•	•		

PSI	Proof stamp illegible	1			I				l			
	Proof stamp missing											
	Rings and bulges on case											
	(Action) release doesn't work											
	Rings in chamber		1									7
	Ring in sholder											
	Rim srem											
	Stems bottom chambers									3		3
	Stems bbl extension											
	Stock cracked or broken											
SCX	Shell catches											
SHI	Short indent											
SI	Stems incline											
SIC	Stems in chamber											
SL	shaves lead											
SLC	Stems left side of chamber	1										1
SMOC	Stretch marks on case											
SOR	Stem over-ride		1					1				2
SP	Stems port											
SR	Shoulder rough											
	Stems right side of chamber											
SRIC	Specific rings in chamber											
SSOC	Surface scratches on case											
STC	Stems top chamber			1								7
SWE	Safety switch works too easily											
SWH	Safety switch works too hard											
sww	Safety ewitxh won't work											
TD	Tips down											
TU	Tips up											
TWP	Trigger won't pull											
TWR	Trigger won't retract											
UNCN-T	Uncoded					2						2
	Extracts hard		1									1
н	High											
	Low											
	Left											
	Right											
	Doesn't Group											
	Front sight tipped											
	Rear sight tipped											
	Rear sight base raised											
	Front sight raised											
	Front sight loose											
I JIL	i form signit loose				l				l			

RSTL	Rear sight loose								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
ввв	Barrel bracket cracked or broken at proof								
вс-Р	Blows cases at proof							1	1
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DLOS-P	Doesn't lock over shells at proof								
ESB-P	Ejector sticks back at proof								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof								
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions		1						1

Summary	Total Test + Pro		1280 333								Test Date:					
	Overali R	al Rejected: Reject Rate:	26.02													totals
		Shot:	96	778	134	60		104				26				1198
	Proof	Rejected: Percent:	0 0.0	172 22.1	2 1.5	0 0.0	0	1 1.0	0	0	0	0 0.0	0	0	0	175 14.8
		Shot:	56	810	56	50		58		12	5	26		32		1105
	Test	Rejected: Percent:	15 26.8	123 15.2	9 16.1	5 10.0	0	2 3.4	0	2 16.7	1 20.0	0 0.0	0	1 3.1	0	158 14.3
		Shot:	8	91	5	45		6				3				158
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0	0 0.0	0	0	0	0 0.0	0	0	0	9 9.0
CODE	MALFUNCTION INI	DEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber			2												ž
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches		13	22		2										37
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full mag	azine														
CD	Case dented															
СН	Closes hard			11												11
CLM	Can't laod magazine															
co	Cut-off															
CR	Cuts rim															
cs	Cases swell															
CTOG	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action ba	ar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject				1											i
DEL	Doesn't eject live round															

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
DFB	Doesn't feed back														
DFU	Doesn't feed up														
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up								2	1					3
DS	Dead safe														
DX	Doesn't extract		3												3
DXL	Doesn't extract live round														
EDS	Extractor drops shell		2	1											3
ESB	Ejector sticks back		2												Ž
ESCR	Empty shell catches receiver		1												1
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens														
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips														
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift		11	3											14
HMSC	Heading mismatch-steps on case														
HPA	High pressure ammo														
HUR	Hard under rail		2												2
JCS	Jumps cartridge														
JM	Jumps magazine		36												36
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard														

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
OR	Over-rides		10				2								12
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber			1											1
RIS	Ring in sholder												1		1
RS	Rim srem														
SBC	Stems bottom chambers		1												1
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline		5												5
SIC	Stems in chamber		2												2
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride		12												12
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
ssoc	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety ewitxh won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard	2	1	3	3										9
н	High														
LO	Low														
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group									<u> </u>					
FSST	Front sight tipped														

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
RSTT	Rear sight tipped														
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DLOS-P	Doesn't lock over shells at proof														
ESB-P	Ejector sticks back at proof														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof		23	2			1								26
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions		149												143

Summary	Total Test + Proof		1157		-						Test Date:					
	Total F Overall Rej	Rejected: ect Rate:	181 15.64													totals
		Shot:	391	8	185	1		92	4	135	10	2			5	833
	Proof	Rejected:	1	0	0	0	0	0	0	3	0	0	0	0	0	4
		Percent:	0.3	0.0	0.0	0.0		0.0	0.0	2.2	0.0	0.0			0.0	0.5
	T4	Shot: Rejected:	611 75	37 3	162 17	0	1	71 40	17 7	200 11	0	0	0	0	46 23	1153 177
	Test	Percent:	12.3	8.1	10.5	Ü	,	56.3	41.2	5.5	Ū	0.0	U	Ü	50.0	15.4
		Shot:	64	5	16			8	1	20						114
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0	0	0 0.0	0 0.0	0 0.0	0	0	0	0	0	0 0.0
	1	Percent.	0.0	0.0	0.0	1		0.0		0.0	1					0.0
CODE	MALFUNCTION INDE	x	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber		3													3
ввма	BBL-to-bolt misalignment															
вв	Bolt binds/catches		8		1											9
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of p	osition														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magazi	ne	10		1											11
CD	Case dented															
СН	Closes hard		5		1											8
CLM	Can't laod magazine				1											1
СО	Cut-off															
CR	Cuts rim															ļ
cs	Cases swell					1										
стос	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action bar					ļ										
DBB	Doesn't blow back					ļ				3						3
DCS	Double click in safety switch	ļ				ļ										<u> </u>
DCT	Double click in trigger					ļ										<u> </u>
DCU	Doesn't close-up															<u> </u>
DE	Doesn't eject									1						1
DEL	Doesn't eject live round															

DFB	Doesn't feed back			I	I				I			
	Doesn't feed up										9	9
	Doesn't lock open (after last shell)										9	37
	Doesn't lock-up										1	1
	Dead safe										'	1
											1	1
	Doesn't extract										1	1
	Doesn't extract live round										'	•
	Extractor drops shell											
ESB	Ejector sticks back											
	Empty shell catches receiver											
-	Extractor stems shell											
FA	Fires automatically											
	Follower binds										1	1
	Fails to connect											
FCB	Fore-end cracked or broken											
	Follows-down											
	Fails to fire											
FFP	Flat firing pin											
	Fires on safe											
	Firing pin hits bbl											
FPHI	Firing pin hits inside rim											
FPO	Floor plate opens											
FPOH	Floor plate opens hard											
FSR	Fires when safe is released											
FT	Follower tips					2						3.
gcso	Gas cyl shot off											
HBL	Heavy bolt lift						6					ş
HMSC	Heading mismatch-steps on case											
HPA	High pressure ammo											
HUR	Hard under rail											
JCS	Jumps cartridge											
JM	Jumps magazine	7		1		33		1				42
JO	Jars off											
LB	Light blow											
МАН	Magazine assembles hard											
MCW	Magazine capacity wrong											
	Misfires (ammo)											
MFOP	Magazine follower out of position											
	Magazine loose											
	Magazine loads hard											
	Magazine removes hard											
ОН	Opens hard											
	Over-rides	1	3	2		1		2				9
	Pulls hard											

		1									
	Proof stamp illegible										
PSM	Proof stamp missing										<u> </u>
RBOC	Rings and bulges on case										
RDW	(Action) release doesn't work										
RIC	Rings in chamber	19	7		1						27
RIS	Ring in sholder	12									12
RS	Rim srem										<u> </u>
SBC	Stems bottom chambers									6	5
SBE	Stems bbl extension										
SCB	Stock cracked or broken										<u> </u>
SCX	Shell catches										
SHI	Short indent										
SI	Stems incline	5									5
SIC	Stems in chamber										
SL	shaves lead										
SLC	Stems left side of chamber										
SMOC	Stretch marks on case										
SOR	Stem over-ride				3	1	4				হ
SP	Stems port										
SR	Shoulder rough										
SRC	Stems right side of chamber										
SRIC	Specific rings in chamber										
ssoc	Surface scratches on case										
STC	Stems top chamber	3									3
SWE	Safety switch works too easily										
SWH	Safety switch works too hard										
sww	Safety ewitxh won't work										
TD	Tips down										
TU	Tips up										
TWP	Trigger won't pull										
TWR	Trigger won't retract										
UNCN-T	Uncoded									4	4
XH	Extracts hard	2	3	1							6
н	High										
	Low										
LEFT	Left										
RIGHT	Right										
DG	Doesn't Group										
FSST	Front sight tipped										
	Rear sight tipped								Ì		
	Rear sight base raised										
	Front sight raised										
	Front sight loose										
	-				·				1		

							1			
RSTL	Rear sight loose									
MGPT-G	Missing parts at target									
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DLOS-P	Doesn't lock over shells at proof									
ESB-P	Ejector sticks back at proof					2				2
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof	1				1				2
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions									

Summary	Total Test + Pr	oof Failures al Rejected:	791 147								Test Date:					
		Reject Rate:	18.58													totals
		Shot:	146	23	35	3		239	296	27		45				814
	Proof	Rejected: Percent:	35 24.0	0 0.0	1 2.9	0 0.0	0	2 0.8	4 1.4	0 0.0	0	0 0.0	0	0	0	42 5.2
		Shot:	83	41	155	3		110	251			45			61	749
	Test	Rejected: Percent:	1 1.2	1 2.4	49 31.6	0 0.0	0	14 12.7	34 13.5	0	0	0 0.0	0	0	0 0.0	99 13.2
		Shot:	78	46	37	6		121	43							331
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	1 16.7	0	0 0.0	5 11.6	0	0	0	0	0	0	6 1.8
CODE	MALFUNCTION IN	IDEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds															
BABS	Bulge at body shoulder								4							4
BAC	Burr at chamber															
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches							1	2							3
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
ВС	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full mag	gazine						1								1
CD	Case dented															
СН	Closes hard		1		6				2							9
CLM	Can't laod magazine															
СО	Cut-off															
CR	Cuts rim															
cs	Cases swell															
CTOG	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action b	ar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round							1								1

n't feed back n't feed up n't lock open (after last shell) n't lock-up safe														
n't lock open (after last shell) n't lock-up safe														<i>i</i>
n't lock-up safe														
safe														
														<u> </u>
n't extract														
n't extract live round														
ctor drops shell			1			4								5
or sticks back							4							4
·														
vs-down														
to fire			1											1
ring pin														
on safe														
pin hits bbl														
pin hits inside rim														
plate opens														
plate opens hard														
when safe is released														
ver tips			2											3:
cyl shot off														
y bolt lift			4			1	2							7
ing mismatch-steps on case														
pressure ammo														
under rail														
s cartridge														
s magazine			8			1	6							15
off														
blow														
zine assembles hard														
zine capacity wrong			1											1
es (ammo)														
zine follower out of position														
zine loose														
s hard														
rides														
hard														
ctt a weet to p p p p weet to p p p weet to p p p p p p weet to p p p p p weet to p p p p p p p p weet to p p p p p p p p p p p p weet to p p p p p p p p p p p p p p p p p p	of fire Ing pin Ing pin Ing safe Ing pin hits bbl Ing hits inside rim Ing pin	tor stems shell tutomatically er binds to connect and cracked or broken s-down to fire ting pin ton safe pin hits bbl pin hits inside rim tolate opens tolate opens tolate opens hard when safe is released er tips v/ shot off tolate in tips to cartridge to magazine tiff tolow time assembles hard time capacity wrong to se (ammo) time follower out of position time loose time loose time removes hard thard tides	tor stems shell tutomatically er binds to connect and cracked or broken s-down to fire ting pin to safe pin hits bbl pin hits inside rim tolate opens tolate opens tolate opens hard when safe is released er tips v/ shot off tolate it is inside to it is in	tor stems shell automatically er binds connect and cracked or broken s-down of fire an pin an safe pin hits bbl pin hits inside rim blate opens blate opens hard when safe is released er tips a gainsmatch-steps on case ressure ammo ander rail a cartridge a magazine a fi fillow dine assembles hard dine capacity wrong s (ammo) ander loose dine loose dine loose dine loose dine loose dine removes hard dides	tor stems shell nutomatically er binds connect nd cracked or broken s-down of fire 1 1 ng pin ng pin ng pin pin hits inside rim blate opens blate opens blate opens blate opens certifys 2 dishot off bott lift q q mismatch-steps on case ressure ammo nder rail cartridge magazine ff slow inie assembles hard inie assembles hard inie loose inie removes hard inie removes	tor stems shell uutomatically er binds o connect ond cracked or broken s-down of fire on g pin on safe pin hits bbl opin hits inside rim olate opens hard when safe is released er tips olate opens hard when safe is released er tips olate opens hard when safe is released er tips olate opens hard when safe is released er tips olate opens hard when safe is released er tips olate opens hard when safe is released er tips olate opens hard when safe is released er tips olate opens hard when safe is released er tips olate opens hard when safe is released er tips olate opens hard when safe is released er tips olate opens hard when safe is released er tips olate opens hard olate opens har	tor stems shell ututomatically er binds co connect on discreted or broken sides sides on binds on bind	tor stems shell tutomatically er binds > connect Indicacked or broken Indicacked or	tor stems shell tutomatically er bibds connect di cracked or broken se-down in gipin in safe join hists bibl join hists bibl join hist sinder rim late opens late opens hard when safe is released er tips 2 in short gi gimsmatch-steps on case ressure ammo norder rail controlled magazine fi fi fi fi fi fi fi fi fi f	Tor stems shell Lutomatically Connect tor stems shell tor stems shell tor stems shell tor stems shell to the stems shell to connect to	too stems shell Lutomatically The rinds Commet Com	ticr stems shell uttornationally uttornationally re rounds re roun	Increases shell with a second control of the	

PSI	Proof stamp illegible					l				
	Proof stamp missing									
	Rings and bulges on case									
	(Action) release doesn't work					4				
	Rings in chamber		2			1				3
	Ring in sholder		20							30
	Rim srem									
	Stems bottom chambers		3							3
	Stems bbl extension									
	Stock cracked or broken									
	Shell catches									
SHI :	Short indent									
	Stems incline									
SIC	Stems in chamber									
SL :	shaves lead									
SLC	Stems left side of chamber				1					1
SMOC	Stretch marks on case									
SOR :	Stem over-ride	1			4					\$
SP :	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber					1				ì
SRIC	Specific rings in chamber									
SSOC	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH :	Safety switch works too hard									
SWW	Safety ewitxh won't work									
TD .	Tips down									
TU .	Tips up									
TWP	Trigger won't pull									
	Trigger won't retract									
UNCN-T	Uncoded									
XH	Extracts hard		1			12				13
HI	High									
	Low									
	Left									
	Right					1				1
	Doesn't Group			1		4				5
	Front sight tipped									
	Rear sight tipped									
	Rear sight base raised									
	Front sight raised									
	Front sight loose			-		 				

							1		_	
RSTL	Rear sight loose									
MGPT-G	Missing parts at target									
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DLOS-P	Doesn't lock over shells at proof									
ESB-P	Ejector sticks back at proof									
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof	16	1		2	1				20
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions	19				3				22

Summary	Total Test + Pro		824								Test Date:					
		al Rejected: Reject Rate:	113 13.71													totals
		Shot:	12	196	202	26		61		2		37			26	562
	Proof	Rejected: Percent:	0 0.0	2 1.0	0 0.0	6 23.1	0	1 1.6	0	0 0.0	0	1 2.7	0	0	0 0.0	10 1.8
		Shot:	11	114	409	151		47		18		38			26	814
	Test	Rejected:	0 0.0	5 4.4	81 19.8	4 2.6	0	5 10.6	0	2 11.1	0	5 13.2	0	0	1 3.8	103 12.7
		Percent: Shot:	0.0	6	38	151		70.0	I	2		6		ı	3.0	205
	Target	Rejected:	0	0	0	0	0	0	0	0	0	0	0	0	0	9
		Percent:		0.0	0.0	0.0		0.0		0.0		0.0				G.O
CODE	MALFUNCTION IN	DEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber				1			5								6
ВВМА	BBL-to-bolt misalignment															
вв	Bolt binds/catches				17											17
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine	!														
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full mag	gazine														
CD	Case dented															
СН	Closes hard			2	7											9
CLM	Can't laod magazine			2	2											4
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action b	ar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															

DFB [Doesn't feed back									
	Doesn't feed up									
	'									
	Doesn't lock open (after last shell)					4				
	Doesn't lock-up					1				1
-	Dead safe									
	Doesn't extract									
	Doesn't extract live round									
	Extractor drops shell		1	2					1	4
	Ejector sticks back									
	Empty shell catches receiver									
ESS E	Extractor stems shell									
FA F	Fires automatically									
FB F	Follower binds									
FC F	Fails to connect									
FCB F	Fore-end cracked or broken									
FD F	Follows-down									
FF F	Fails to fire									
FFP F	Flat firing pin									
FOS F	Fires on safe									
FPHB F	Firing pin hits bbl									
FPHI F	Firing pin hits inside rim									
FPO F	Floor plate opens									
FPOH F	Floor plate opens hard									
FSR F	Fires when safe is released									
FT F	Follower tips	1								4
GCSO (Gas cyl shot off									
HBL I	Heavy bolt lift		37							37
HMSC H	Heading mismatch-steps on case									
HPA I	High pressure ammo									
HUR I	Hard under rail									
JCS .	Jumps cartridge									
JM .	Jumps magazine						5			5
JO .	Jars off									
LB I	Light blow									
1 HAM	Magazine assembles hard					1				1
MCW I	Magazine capacity wrong									
	Misfires (ammo)									
MFOP I	Magazine follower out of position									
	Magazine loose									
MLH I	Magazine loads hard									
	Magazine removes hard									
он (Opens hard									
OR (Over-rides			2						2
PH F	Pulls hard		1							

PSI	Proof stamp illegible			l			l			
										
	Proof stamp missing									
	Rings and bulges on case									
	(Action) release doesn't work		_							
	Rings in chamber		5							\$
	Ring in sholder									
	Rim srem									
SBC	Stems bottom chambers		2							2
	Stems bbl extension									
SCB	Stock cracked or broken									
SCX	Shell catches									
SHI	Short indent									ĺ
SI	Stems incline									ĺ
SIC	Stems in chamber									
SL	shaves lead									
SLC	Stems left side of chamber									
	Stretch marks on case									
SOR	Stem over-ride									
	Stems port									
	Shoulder rough									
	Stems right side of chamber									
	Specific rings in chamber									
	Surface scratches on case									
	Stems top chamber		1							1
	Safety switch works too easily									
	Safety switch works too hard									
	Safety ewitxh won't work									
	Tips down									
	Tips up									
TWP	Trigger won't pull									
	Trigger won't retract									
	Uncoded									
	Extracts hard		8							8
7(1)	Extracts flard									
HI	High									
	Low									
	Left									
	Right									
	Doesn't Group									
	Front sight tipped									
	Rear sight tipped									
	Rear sight base raised									
	Front sight raised									
FSTL	Front sight loose						<u> </u>			<u> </u>

RSTL	Rear sight loose							
MGPT-G	Missing parts at target							
UNCN-G	Uncoded nonconformity at target							
AI-P	Assembly incompleye at proof							
BBB	Barrel bracket cracked or broken at proof							
вс-Р	Blows cases at proof							
BEB-P	Barrel extension broken at proof							
BLP-P	Blanked primer at proof							
BLSO-P	Barrel lug shot off at proof							
BP-P	Blown primer at proof							
BS-P	Barrel split at proof							
DLOS-P	Doesn't lock over shells at proof							
ESB-P	Ejector sticks back at proof					1		1
FCB-P	Fore-end cracked at proof							
FESO-P	Fore-end shot off at proof							
FF-P	Fails to fire at proof							
GCSO-P	Gas cylinder shot off at proof							
MSI-P	Magnaflux stamp illegible on bbl							
MSM-P	Magnaflux stamp missing on bbl							
PP-P	Pierced primer at proof			1				ì
SCB-P	Stock cracked or broken at proof							
UNCM-P	Uncoded proof malfunctions	2	6					8

Summary	Total Test + Pro	of Failures I Rejected:	857 120								Test Date:					
		eject Rate:	14.00													totals
		Shot:	298	211	105	13		64		44	20	5	3		39	802
	Proof	Rejected: Percent:	1 0.3	3 1.4	0 0.0	0 0.0	0	1 1.6	0	0 0.0	0 0.0	0 0.0	0 0.0	0	2 5.1	7 0.9
		Shot:	435	94	58	76		68			76			_	43	850
	Test	Rejected: Percent:	43 9.9	7 7.4	7 12.1	1 1.3	0	10 14.7	0	0	25 32.9	0	0	0	20 46.5	113 13.3
		Shot:	43	9	5	59		5			2					123
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0	0 0.0	0	0	0 0.0	0	0	0	0	0 0.0
CODE	MALFUNCTION INC	DEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
AB	Action binds														2	2
BABS	Bulge at body shoulder		2													5
BAC	Burr at chamber		2		2	1										5
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches		4		1			1								6
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of	f position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full maga	azine	13	1												14
CD	Case dented															
СН	Closes hard		5		1											8
CLM	Can't laod magazine															
СО	Cut-off															
CR	Cuts rim															
cs	Cases swell															
CTOG	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action ba	r														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject		1													1
DEL	Doesn't eject live round															

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
DFB	Doesn't feed back														
DFU	Doesn't feed up													1	1
DLO	Doesn't lock open (after last shell)									4					4
DLU	Doesn't lock-up														
DS	Dead safe														
DX	Doesn't extract													10	10
DXL	Doesn't extract live round														
EDS	Extractor drops shell						1							6	?
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds													1	1
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens		1												1
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips														
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift		1	1											5
HMSC	Heading mismatch-steps on case														
НРА	High pressure ammo														
HUR	Hard under rail	4	1												S
JCS	Jumps cartridge														
JM	Jumps magazine		2	2			5								9
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard														
MCW	Magazine capacity wrong						2								2
MFA	Misfires (ammo)														
мгор	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard	1	1												1

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
OR	Over-rides	2													3
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work									1					1
RIC	Rings in chamber	8													ä
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers														
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline	2													2
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride									20					26
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety ewitxh won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard						1								1
н	High														
LO	Low														
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
RSTT	Rear sight tipped														
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof													2	3
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DLOS-P	Doesn't lock over shells at proof														
ESB-P	Ejector sticks back at proof														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof						1								1
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof		2												ž
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions	1	1												2

Summary	Total Test + Pro	oof Failures	934								Test Date:					
	Tota	al Rejected: Reject Rate:	71 7.60													totals
	0.0.0	Shot:	553	101	185				1			73			15	927
	Proof	Rejected:	0	0	8	0	0	0	0	0	0	1	0	0	1	10
		Percent:	0.0	0.0	4.3							1.4			6.7	1.1
		Shot:	585	84	155		11					74			15	924
	Test	Rejected: Percent:	21 3.6	4 4.8	22 14.2	0	4 36.4	0	0	0	0	7 9.5	0	0	3 20.0	61 8.6
		Shot:	70	10	18			1	ı			10		I		108
	Target	Rejected:	0	0	0	0	0	0	0	0	0	0	0	0	0	0
		Percent:	0.0	0.0	0.0			_				0.0		_		0.0
CODE	MALFUNCTION IN	DEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds															
BABS	Bulge at body shoulder		1													1
BAC	Burr at chamber				1											1
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches		1		2											3
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full mag	gazine	2													2
CD	Case dented															
СН	Closes hard															
CLM	Can't laod magazine															
СО	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стос	Chamber torn or gouged												1			
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action b	ar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round												1			

DFB	Doesn't feed back			I	1		I	l	1	l			
DFU	Doesn't feed up											1	i
DLO	Doesn't lock open (after last shell)											'	
DLU	Doesn't lock-up												
DS	Dead safe												
		2								1			3
DX DXL	Doesn't extract	2								'			
	Doesn't extract live round	14											14
EDS	Extractor drops shell	14											14
ESB	Ejector sticks back												
ESCR	Empty shell catches receiver			-									
ESS	Extractor stems shell												
FA	Fires automatically												
FB	Follower binds												
FC	Fails to connect												
FCB	Fore-end cracked or broken												
FD	Follows-down												
FF	Fails to fire					4							4
FFP	Flat firing pin												
FOS	Fires on safe												
FPHB	Firing pin hits bbl												
FPHI	Firing pin hits inside rim												
FPO	Floor plate opens												
FPOH	Floor plate opens hard												
FSR	Fires when safe is released												i
FT	Follower tips												
GCSO	Gas cyl shot off												i
HBL	Heavy bolt lift												
HMSC	Heading mismatch-steps on case												
HPA	High pressure ammo												
HUR	Hard under rail			2									2
JCS	Jumps cartridge												
JM	Jumps magazine		4	2						5			11
JO	Jars off												
LB	Light blow												
МАН	Magazine assembles hard												
MCW	Magazine capacity wrong												
MFA	Misfires (ammo)												
MFOP	Magazine follower out of position												
ML	Magazine loose												
MLH	Magazine loads hard												
MRH	Magazine removes hard			1						1			5
ОН	Opens hard												
OR	Over-rides			1									1
PH	Pulls hard												

							1	1		
	Proof stamp illegible									
PSM	Proof stamp missing									
RBOC	Rings and bulges on case									<u> </u>
RDW	(Action) release doesn't work									
RIC	Rings in chamber	1	5							6
RIS	Ring in sholder		5							5
RS	Rim srem									
SBC	Stems bottom chambers									
SBE	Stems bbl extension									
SCB	Stock cracked or broken									
scx	Shell catches									
SHI	Short indent									
SI	Stems incline									
SIC	Stems in chamber									
SL	shaves lead									
SLC	Stems left side of chamber									
SMOC	Stretch marks on case									
SOR	Stem over-ride									
SP	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber		1						2	3
SRIC	Specific rings in chamber									
ssoc	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
sww	Safety ewitxh won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
XH	Extracts hard		2							2
н	High									
	Low									
LEFT	Left									
RIGHT	Right									
DG	Doesn't Group									
FSST	Front sight tipped									
	Rear sight tipped									
	Rear sight base raised									
	Front sight raised									
	Front sight loose									
	-									

						1				
RSTL	Rear sight loose									
MGPT-G	Missing parts at target									
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof								1	1
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DLOS-P	Doesn't lock over shells at proof									
ESB-P	Ejector sticks back at proof						1			1
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof		8							8
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions									

					F1001 - 1	est - Target						
Summary	7	Proof Failures Total Rejected: all Reject Rate:	1017 193 18.98								Test Date:	
		Shot:	453	65	18	2	235	150				
	Proof	Rejected:		4	32	0	40	2	0	0	0	
	FIOOI	Percent:	0.2	6.2	177.8	0.0	17.0	1.3	U	U	U	
		_										
		Shot:	556	7	96	44	72	163				
	Test	Rejected:	47	5	18	7	17	14	0	0	0	(
		Percent:	8.5	71.4	18.8	15.9	23.6	8.6				
		Shot:	188			42	92	15				
	Target	Rejected:	1	0	0	4	1	0	0	0	0	(
	J	Percent:	0.5			9.5	1.1	0.0				
CODE	MALFUNCTION	INDEX	700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 ML	
AB	Action binds											
ASFB	Action spring follower bind	le l	+	+		+						
BABS	Bulge at body shoulder	15	+									
BAC	Burr at chamber		3									
ВВМА	BBL-to-bolt misalignment											
BB	Bolt binds/catches											
BCOBS	Bolt catches on bolt stop		-									
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases											
BHR	Bolt hits receiver											
BHS	Bolt plug hits safety switch	1										
BLOP	Bar lock or disconnector o											
BLSO	Barrel lug shot off	,										
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magazi	ne										
BWCD	Bolt won't cam down											
BWCFM	Bolt won't close over full m	nagazine										
CBS-F	Shells catch on bbl suppor											
CBS-L	Shells catch on bbl suppor	rt-loading										
CC	Carrier catches on shells,r	mag,receiver										
CD	Case dented											ļ
CH	Closes hard		1	3								1
CHAB	Carrier hits action bar											1
CLM	Can't laod magazine											
CO	Cut-off											
CR CS	Cuts rim Cases swell											1
CTOG												1
CTP	Chamber torn or gouged Creepy trigger pull											1
CWSB	Creepy trigger pull Cams wrong side of action	har						-				1
DBB	Doesn't blow back	ı bai		+						+		1

DOO	In 11 11 11 11 11 11 11 11 11 11 11 11 11				1			ı	1	1	1
DCS	Double click in safety switch										
DCT	Double click in trigger										
DCU	Doesn't close-up										
DE	Doesn't eject	1					1				
DEL	Doesn't eject live round										
DFB	Doesn't feed back										
DFU	Doesn't feed up										
DLO	Doesn't lock open (after last shell)										
	Doesn't lock-up						5				
DS	Dead safe										
DSM	Drops shell-magazine										
DTL	Doesn't trip latch										
DX	Doesn't extract						2				
DXL	Doesn't extract live round										
EDS	Extractor drops shell		1								
ESB	Ejector sticks back	6		18		3					
ESCR	Empty shell catches receiver										
	Extractor stems shell										
FA	Fires automatically										
FB	Follower binds										
FC	Fails to connect										
FCB	Fore-end cracked or broken						1				
	Follows-down						·				
	Fails to fire										
	Fails to feed from magazine										
	Flat firing pin										
FOS	Fires on safe										
FPHB	Firing pin hits bbl										
	Firing pin hits inside rim										
	Floor plate opens				1						
FPOH	Floor plate opens hard				'						
	Fires when safe is released										
	Follower tips	8				1					
GCSO	Gas cyl shot off	·				ı					
GRSO	Guide ring shot off										
	Heavy bolt lift	3									
		3									
HINSC	Heading mismatch-steps on case										
HPA HUE	High pressure ammo Hard under extractor	1								-	
HUE											
HUR	Hard under rail										
ILOP	Int. latch out of position										
ILRM	Int. latch ret. Missing										
ILSB	Int. latch stud broken										
ILSP	Int. latch spring out of position										
JCS	Jumps cartridge										
JL	Jumps latch									ļ	
JM	Jumps magazine									ļ	
JO	Jars off										
LB	Light blow										

MCSCO Magazine capacity wrong MFA Misfires (ammo) MFA Misfires (am	MAH	Magazine assembles hard								
Magazine classed Magazine (oliver out of position Magazine (oliver out out of position Magazine (oliver out out of position Magazine (oliver out	MCSO									
MFA Melifres (ammo) Micro Magazine follower out of position Micro Micro Magazine follower out of the micro Mic										
MEOP	MEA	Miofires (amms)	_							
ML Magazine loses ML Magazine removes hard OH Opens hard OR Over-rides PH Pulls hard OR Over-rides PTO Stamp nilegible PTO Sta	MEOD									
MEH Magazine removes hard OH Opens hard OH O										
MRH	ML									
OPE Opens hard OPEN OP			1							
OR										
Pills hard Pil	ОН						ļ			
PSM	OR						1			
PRMC	PH									
RBOC	PSI									
RDW (Action) release doesn't work	PSM									
RIC										
RIS Ring in sholder										
SEC Stems bottom chambers 2	RIC		9			2				
SEC Stems bottom chambers 2	RIS	Ring in sholder								
SEE Stems bil extension SCR Stock cracked or broken SCR Stems incline Stock cracked Stock crac	RS	Rim srem								
SEE Stems bil extension SCR Stock cracked or broken SCR Stems incline Stock cracked Stock crac	SBC	Stems bottom chambers	2							
SCX Shell catches Shell	SBE	Stems bbl extension								
Scheman	SCB	Stock cracked or broken								
SHI	SCX									
Stems incline										
SL			4							
SL	SIC									
SLC Stems left side of chamber 1										
SMOC Stretch marks on case 9 SOR Stem over-ride 1 SP Stems port 9 SR Shoulder rough 9 SRC Stems right side of chamber 9 SRC Stems right side of chamber 9 SRIC Specific rings in chamber 9 SSC shell stems carrier 9 SSOC Surface scratches on case 9 STC Stems top chamber 9 SWE Safety switch works too easily 9 SWH Safety switch works too hard 9 SWW Safety switch work too hard 9 SWW	SLC		1				1			
SOR Stem over-ride 1 3 3	SMOC		·							
SP Stems port SR Shoulder rough SRC Stems right side of chamber SRIC Specific rings in chamber SSC shell stems carrier SSOC Surface scratches on case STC Stems top chamber SWE Safety switch works too easily SWH Safety switch works too hard SWW Safety ewibth won't work TD Tips down TU Tips up TWP Trigger won't pull TWR Trigger won't retract UNCOL-T Uncoded KH Extracts hard 8 XHB Extractor hits bbl				1			3			
SR Shoulder rough	SP			<u>'</u>			 			
SRC Stems right side of chamber SRIC Specific rings in chamber SSC shell stems carrier SSOC Surface scratches on case STC Stems top chamber SWE Safety switch works too easily SWH Safety switch works too hard SWW Safety switch work work too hard TD Tips down TU Tips up TWP Trigger won't pull TWR Trigger won't retract UNCN-T Uncoded XH Extracts hard 8 AHB Extractor hits bbl	SR	Shoulder rough								
SRIC Specific rings in chamber	SRC	Stems right side of chamber								
SSC shell stems carrier SSOC Surface scratches on case STC Stems top chamber SWE Safety switch works too easily SWH Safety switch works too hard SWW Safety ewitxh won't work TD Tips down TU Tips up TWP Trigger won't pull TWR Trigger won't retract UNCN-T Uncoded XH Extracts hard 8 XHB Extractor hits bbl	SRIC									
SSOC Surface scratches on case	990									
STC Stems top chamber SWE Safety switch works too easily SWH Safety switch works too hard SAfety switch work too hard SAfety ewitxh won't work TD Tips down Tips up Tips up TWP Trigger won't pull Trigger won't retract TWR TWRON-T Uncoded 6 XH Extracts hard 8 11 XHB Extractor hits bbl TIME	550C									
SWE Safety switch works too easily SWH Safety switch works too hard SWW Safety ewitxh won't work TD Tips down TU Tips up TWP Trigger won't pull TWR Trigger won't retract UNCN-T Uncoded XH Extracts hard 8 11 XHB Extractor hits bbl	STC	Stems ton chamber		 			 	 		
SWH Safety switch works too hard SWW SWW Safety ewitxh won't work SWW TD Tips down Tips up TU Tips up Tips up TWP Trigger won't pull Trigger won't retract TWR Trigger won't retract Tips up UNCN-T Uncoded Uncoded XH Extracts hard 8 XHB Extractor hits bbl Tips up	SIVE			-		-	-	-		
SWW Safety ewitxh won't work										
TD Tips down	CVVVV	Safety switch works too hard		ļ			!	<u> </u>		
TU Tips up Image: Control of the contro				 			 	 		
TWP Trigger won't pull Image: Control of the control o	TU									
TWR Trigger won't retract 6 UNCN-T Uncoded 6 XH Extracts hard 8 XHB Extractor hits bbl	TAID			ļ			ļ	ļ		
UNCN-T Uncoded 6 ————————————————————————————————————	TVVP	Trigger won't pull					ļ			
XH Extracts hard 8 11		irigger won't retract								
XHB Extractor hits bbl				ļ	6		ļ			
			8			11				
	XHB	Extractor hits bbl								
HI High										
	HI	High								

LO	Low								
LEFT	Left								
RIGHT	Right								
DG	Doesn't Group	1			4	1			
FSST	Front sight tipped	<u>'</u>				<u>'</u>			
RSTT	Rear sight tipped								
RSBR	Rear sight base raised								
FSTR	Front sight raised								
FSTL	Front sight loose								
RSTL	Rear sight loose								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
ONCN-G	Oncoded noncomornity at target								
AI-P	Assembly incompleye at proof								
RRR	Barrel bracket cracked or broken at proof								
BBB BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DLOS-P	Doesn't lock over shells at proof								
ESB-P	Ejector sticks back at proof						1		
FCB-P	Fore-end cracked at proof						'		
FESO-P	Fore-end cracked at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
GRSO-P	Guide ring shot off at proof								
MCSO-P	Magazine cap shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl				 				
PP-P	Pierced primer at proof		 		-	1			
SCB-P	Stock cracked or broken at proof		 			<u> </u>			
UNCM-P	Uncoded proof malfunctions	1	3	32	-	39	1		
ONCIVI-P	Toncoded proof manufictions	ı	<u> </u>	32	L	১৬	_ '		

					Proof - 1	est - Target						
Summary	Total Test + Proof Failures Total Rejected: Overall Reject Rate:		716 123 17.18								Test Date:	1/31/2003
		Shot:	89	46	46	1	494		38			
	Proof	Rejected:	0	7	4	0	52	0	0	0	0	0
	P1001	Percent:	0.0	15.2	8.7	0.0	10.5	U	0.0	U	U	U
		_		10.2	0.7	0.0			0.0			
		Shot:	330				296				27	
	Test	Rejected:	26	0	0	0	26	0	0	0	0	0
		Percent:	7.9				8.8				0.0	
		Shot:	40	8	29		225					
	Target	Rejected:	6	0	0	0	2	0	0	0	0	0
	J	Percent:	15.0	0.0	0.0		0.9					
CODE	MALFUNCTION	INDEX	700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 ML	
AB	Action binds			+								
ASFB	Action binds Action spring follower bind	le l								-		
BABS	Bulge at body shoulder	is										
BAC	Burr at chamber						1					
BBMA	BBL-to-bolt misalignment						· '					
BB	Bolt binds/catches		3				5					
BCOBS	Bolt catches on bolt stop		3									
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower						1					
BC	Blows cases						<u> </u>					
BHR	Bolt hits receiver											
BHS	Bolt plug hits safety switch											
BLOP	Bar lock or disconnector of											
BLSO	Barrel lug shot off	di or pooliion										
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magazii	ne										
BWCD	Bolt won't cam down											
BWCFM	Bolt won't close over full m	nagazine										
CBS-F	Shells catch on bbl suppor	rt-feeding										
CBS-L	Shells catch on bbl suppor											
CC	Carrier catches on shells,n	mag,receiver										
CD	Case dented											
СН	Closes hard		3									
CHAB	Carrier hits action bar											
CLM	Can't laod magazine											
co	Cut-off											
CR	Cuts rim											
CS	Cases swell											
CTOG	Chamber torn or gouged											
CTP	Creepy trigger pull											
CWSB	Cams wrong side of action	n bar										
DBB	Doesn't blow back											

DCS	Double click in safety switch				1		1	
DCT	Double click in trigger							
DCU	Doesn't close-up							
DE	Doesn't eject							
DEL	Doesn't eject live round							
DFB	Doesn't feed back							
	Doesn't feed up							
DLO	Doesn't lock open (after last shell)							
	Doesn't lock-up							
DS	Dead safe							
DSM	Drops shell-magazine							
	Doesn't trip latch							
DX	Doesn't extract	1						
DXL	Doesn't extract live round	1						
EDS	Extractor drops shell	1						
ESB	Ejector sticks back							
ESCR	Empty shell catches receiver							
	Extractor stems shell							
FA	Fires automatically							
FB	Follower binds							
FC	Fails to connect							
FCB	Fore-end cracked or broken							
FD	Follows-down							
FF	Fails to fire							
FFM	Fails to feed from magazine							
FFP	Flat firing pin							
FOS	Fires on safe							
FPHB	Firing pin hits bbl							
FPHI	Firing pin hits inside rim							
	Floor plate opens							
FPOH	Floor plate opens hard							
FSR	Fires when safe is released							
	Follower tips	2						
GCSO	Gas cyl shot off							
GRSO	Guide ring shot off	-						
	Heavy bolt lift	2		1				
HMSC	Heading mismatch stone on soci			l l				
	Heading mismatch-steps on case							
HPA	High pressure ammo							
	Hard under extractor							
HUR	Hard under rail	-						
ILOP	Int. latch out of position							
ILRM	Int. latch ret. Missing							
ILSB	Int. latch stud broken	ļ						
ILSP	Int. latch spring out of position	ļ						
JCS	Jumps cartridge							
JL	Jumps latch							
JM	Jumps magazine	1		5				
JO	Jars off							
LB	Light blow							

MAH	Magazine assembles hard		I		I	1	1	
MCSO	Magazine cap shot off							
MCW								
	Magazine capacity wrong							
MFA	Misfires (ammo)							
MFOP	Magazine follower out of position							
ML	Magazine loose							
MLH	Magazine loads hard							
MRH	Magazine removes hard							
ОН	Opens hard							
OR	Over-rides	3						
PH	Pulls hard							
PSI	Proof stamp illegible							
PSM	Proof stamp missing							
RBOC	Rings and bulges on case							
RDW	(Action) release doesn't work							
RIC	Rings in chamber							
RIS	Ring in sholder							
RS	Rim srem							
SBC	Stems bottom chambers							
SBE	Stems bbl extension							
SCB	Stock cracked or broken							
SCX	Shell catches							
SHI	Short indent							
SI	Stems incline	7		8				
SIC	Stems in chamber	'		-				
SL	shaves lead							
SLC	Stems left side of chamber							
SMOC	Stretch marks on case	_						
SOR	Stem over-ride			1				
				l l				
SP	Stems port							
SR	Shoulder rough							
SRC	Stems right side of chamber							
SRIC	Specific rings in chamber							
SSC	shell stems carrier							
SSOC	Surface scratches on case							
STC	Stems top chamber							
SWE	Safety switch works too easily							
SWH	Safety switch works too hard							
SWW	Safety ewitxh won't work							
TD	Tips down							
TU	Tips up							
TWP	Trigger won't pull							
TWR	Trigger won't retract							
UNCN-T	Uncoded							
XH	Extracts hard	2		4				
XHB	Extractor hits bbl							
1								
НІ	High							
	. · ·	1						

LO	Low	1						
LEFT	Left							
RIGHT	Right							
DG	Doesn't Group	5			2			
FSST	Front sight tipped				_			
RSTT	Rear sight tipped							
RSBR	Rear sight base raised							
FSTR	Front sight raised							
FSTL	Front sight loose							
RSTL	Rear sight loose							
MGPT-G	Missing parts at target							
UNCN-G	Uncoded nonconformity at target							
	, , ,							
AI-P	Assembly incompleye at proof							
BBB	Barrel bracket cracked or broken at proof							
BBB BC-P	Blows cases at proof							
BEB-P	Barrel extension broken at proof							
BLP-P	Blanked primer at proof							
BLSO-P	Barrel lug shot off at proof							
BP-P	Blown primer at proof							
BS-P	Barrel split at proof							
DLOS-P	Doesn't lock over shells at proof							
ESB-P	Ejector sticks back at proof							
FCB-P	Fore-end cracked at proof							
FESO-P	Fore-end shot off at proof							
FF-P	Fails to fire at proof							
GCSO-P	Gas cylinder shot off at proof							
GRSO-P	Guide ring shot off at proof							
MCSO-P	Magazine cap shot off at proof							
MSI-P	Magnaflux stamp illegible on bbl							
MSM-P	Magnaflux stamp missing on bbl							
PP-P	Pierced primer at proof			3	13			
SCB-P	Stock cracked or broken at proof							
UNCM-P	Uncoded proof malfunctions		7	1	39			