Summary	Total T		698								Test Date:					
	Total Reje Overall Reject		27 3.87													totals
		Shot:	201	114	274	32	81	2	1							705
		jected:	1 0.5	1 0.9	3 1.1	0 0.0	0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	5 0.7
		ercent: Shot: [168	U.9	380	67	78	T 0.0	5	1	1		1			888
	Test Re,	jected:	10	0	6	3	3	0	0	0	0	0	0	0	0	22
	Pe	ercent:	6.0		1.6	4.5	3.8		0.0							3.2
		Shot: [jected:	14 0	0	38 0	7 0	0	0	0	0	<u> </u>	0	<u> </u>	0	0	67 0
		ercent:	0.0	Ü	0.0	0.0	0.0	Ū	v	Ū	v	v	v	v	o o	0.0
ODE	MALFUNCTION INDEX		700 SPS	700 SPS	700 BDL &	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
				SS	ADL											
λB	Action binds															
ABS	Bulge at body shoulder															
AC	Burr at chamber															
ВМА	BBL-to-bolt misalignment															
В	Bolt binds/catches				3											3
COAB	Bolt catches on anti-bind															
COBS	Bolt catches on bolt stop															
COF	Bolt catches on follower															
С	Blows cases															
HR	Bolt hits receiver															
HS	Bolt plug hits safety switch															
LOP	Bar lock or disconnector out of posit	tion														
LSO	Barrel lug shot off															
- 0	Bolt pulls out															
SSM	Bolt stems shell in magazine															
WCD	Bolt won't cam down															
WCFM	Bolt won't close over full magazine															
D	Case dented															
Н	Closes hard				2		1									3
LM	Can't load magazine															
ю	Cut-off															
R	Cuts rim															
s	Cases swell															
TOG	Chamber torn or gouged					1										-1
TP	Creepy trigger pull															
WSB	Cams wrong side of action bar															
ВВ	Doesn't blow back															
)CS	Double click in safety switch															
СТ	Double click in trigger															
CU	Doesn't close-up															
E	Doesn't eject															
EL	Doesn't eject live round															
FB	Doesn't feed back															
FU	Doesn't feed up															
)LO	Doesn't lock open (after last shell)															
OLU	Doesn't lock-up															
DS	Dead safe															
DX	Doesn't extract															
DXL	Doesn't extract live round															
EDS	Extractor drops shell						1									1

ESB	Ejector sticks back		I		I		I	I	I	I	l	1	
ESCR	Empty shell catches receiver												
ESS	Extractor stems shell												
FA	Fires automatically												
FB	Follower binds	+											
FC	Fails to connect	+											
FCB	Fore-end cracked or broken	+											
FD	Follows-down	+											
FF	Fails to fire	+				1							-3
FFP	Flat firing pin					'							,
FOS	Fires on safe	+											
FPHB	Firing pin hits bbl												
FPHI	Firing pin hits inside rim												
FPO	Floor plate opens				2								2
FPOH	Floor plate opens hard	+											
FSR	Fires when safe is released	+											
FT	Follower tips	+		1									1
GCSO	Gas cyl shot off	1		'									· · · · · · · · · · · · · · · · · · ·
HBL	Heavy bolt lift												
HMSC	Heading mismatch-steps on case	1											
HPA	High pressure ammo	+											
HUR	Hard under rail												
JCS	Jumps cartridge	+											
JM	Jumps magazine	+											
JO	Jars off												
LB	Light blow	+											
MAH	Magazine assembles hard	+											
MCW	Magazine capacity wrong												
MFA	Misfires (ammo)	+											
MFOP	Magazine follower out of position												
ML	Magazine loose	5											5
MLH	Magazine loads hard	 											,
MRH	Magazine removes hard	+											
ОН	Opens hard												
OR	Over-rides	3											3
PH	Pulls hard	+ -											
PSI	Proof stamp illegible	+											
PSM	Proof stamp missing												
RBOC	Rings and bulges on case												
RDW	(Action) release doesn't work	1											
RIC	Rings in chamber	1											
RIS	Ring in sholder												
RS	Rim srem												
SBC	Stems bottom chambers												
SBE	Stems bbl extension												
SCB	Stock cracked or broken	1											
SCX	Shell catches												
SHI	Short indent												
SI	Stems incline	1											
SIC		1											
SL	Stems in chamber shaves lead	1											
SLC	Stems left side of chamber						l						i

SMOC	Io							1	1	
	Stretch marks on case									
SOR	Stem over-ride									
SP	Stems port	1								3
SR	Shoulder rough									
SRC	Stems right side of chamber	1								1
SRIC	Specific rings in chamber									
ssoc	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
sww	Safety Switch won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
XH	Extracts hard									
н	High									
LO	Low									
LEFT	Left									
RIGHT	Right									
DG	Doesn't Group									
FSST	Front sight tipped									
RSTT	Rear sight tipped									
RSBR	Rear sight base raised									
FSTR	Front sight raised									
FSTL	Front sight loose									
RSTL	Rear sight loose									
MGPT-G										
UNCN-G	Missing parts at target Uncoded nonconformity at target									
UNCN-G	Oncoded noncomormity at target									
41.5	A 11:									——
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DBF-P	Damaged Bolt Face	1		3						4
DLOS-P	Doesn't lock over shells at proof									
ESBBP-P	Ejector sticks back -Blown Primer cup									
ESBEC-P	Ejector sticks back - Ejector Cresent									
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl		1							1
PP-P	Pierced primer at proof									
SCB-P	Stock cracked or broken at proof									

Summary	Total Te	sted	854								Test Date:					
	Total Rejec	ted:	42													
	Overall Reject F		4.92													totals
		Shot: cted:	405 0	11	144	27 0	182 0	27 0	0	0	0	0	0	0	0	798 2
	Per	cent:	0.0	9.1	0.7	0.0	0.0	0.0	0.0							0.3
		Shot: cted:	476 25	20 2	162 6	85 2	91 3	20	0	0	0	0	0	0	0	854 40
		cent:	5.3	10.0	3.7	2.4	3.3	10.0	U	U	U	U	U	U	U	4.7
		Shot:	34	2	17	9	9	20								91
		cted: cent:	0 0.0	0 0.0	0 0.0	0 0.0	0 0.0	0 0.0	0	U	O	0	O	Ü	0	0 0.0
DE	MALFUNCTION INDEX		700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
					,,,,,,											
3	Action binds															
3S	Bulge at body shoulder															
.c	Burr at chamber															
ВМА	BBL-to-bolt misalignment															
3	Bolt binds/catches		10													10
COAB	Bolt catches on anti-bind															
OBS	Bolt catches on bolt stop															
OF	Bolt catches on follower															
_	Blows cases										<u> </u>					
R	Bolt hits receiver														ļ	
3	Bolt plug hits safety switch							1			1					
OP.	Bar lock or disconnector out of position	on									1				ļ	
0	Barrel lug shot off							ļ			<u> </u>				ļ	
)	Bolt pulls out										ļ				ļ	
SM	Bolt stems shell in magazine															
/CD	Bolt won't cam down															
CFM	Bolt won't close over full magazine															
	Case dented		7				-									
4	Closes hard		7	1		1	1				-				-	3
vi	Can't load magazine					1	2				-					, j
!	Cut-off	-+									1					
	Cuts rim										1					
rog	Cases swell	-+									1					
P OG	Chamber torn or gouged	-+														
VSB	Creepy trigger pull	-+									 				-	
BB	Cams wrong side of action bar	+									-				-	
SS S	Doesn't blow back Double click in safety switch	+														
T		-+									1				1	
U	Double click in trigger Doesn't close-up	-+														
0		+				1										1
L	Doesn't eject Doesn't eject live round	-				 '									1	,
В	Doesn't feed back										1		 			
U	Doesn't feed up	+									1					
LO	Doesn't lock open (after last shell)	-+														
LU	Doesn't lock-up	-+														
s	Dead safe	-+														
OX	Doesn't extract	+			1						1					1
(L	Doesn't extract live round	-+			<u> </u>						1					· '
·	Extractor drops shell	-+			1	1	1	 	-	 	1	+	 	1	1	

	1	1									1		1		
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire		1												3
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens														
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips														
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift														
HMSC	Heading mismatch-steps on case	+		-			 							 	
HPA	High pressure ammo														
HUR	Hard under rail	1		2											3
JCS	Jumps cartridge	'		-											
JM	Jumps magazine	1													3
JO	Jars off	<u> </u>													'
LB	Light blow	-													-
MAH															
	Magazine assembles hard			-										-	
MCW	Magazine capacity wrong														
MFA MFOP	Misfires (ammo)														
	Magazine follower out of position														
ML	Magazine loose						2								2
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard														
OR	Over-rides	5		2											?
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber														
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers														
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline														
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber														
	•	-	•	•	•	•	-	•	•	•		•		-	

SMOC	Stretch marks on case	1					1				
SOR				1							1
SP	Stem over-ride	-		1							1
	Stems port	-									
SR	Shoulder rough	-									
SRC	Stems right side of chamber										
SRIC	Specific rings in chamber										
SSOC	Surface scratches on case	.									
STC	Stems top chamber	1									1
SWE	Safety switch works too easily										
SWH	Safety switch works too hard										
sww	Safety Switch won't work										
TD	Tips down										<u> </u>
TU	Tips up										
TWP	Trigger won't pull										
TWR	Trigger won't retract										
UNCN-T	Uncoded										
XH	Extracts hard										
н	High										
LO	Low										
LEFT	Left										
RIGHT	Right										
DG	Doesn't Group										
FSST	Front sight tipped										
RSTT	Rear sight tipped										
RSBR	Rear sight base raised										
FSTR	Front sight raised										
FSTL	Front sight loose										
RSTL	Rear sight loose										
MGPT-G	Missing parts at target										
UNCN-G	Uncoded nonconformity at target										
Al-P	Assembly incompleye at proof										
BBB	Barrel bracket cracked or broken at proof										
BC-P	Blows cases at proof										
BEB-P	Barrel extension broken at proof										
BLP-P	Blanked primer at proof										
BLSO-P	Barrel lug shot off at proof										
BP-P	Blown primer at proof										
BS-P	Barrel split at proof										
DBF-P	Damaged Bolt Face		1	1							2.
DLOS-P	Doesn't lock over shells at proof										
ESBBP-P	Ejector sticks back -Blown Primer cup										
ESBEC-P	Ejector sticks back - Ejector Cresent										
FCB-P	Fore-end cracked at proof										
FESO-P	Fore-end shot off at proof										
FF-P	Fails to fire at proof										
GCSO-P	Gas cylinder shot off at proof										
MSI-P	Magnaflux stamp illegible on bbl										
MSM-P	Magnaflux stamp missing on bbl										
PP-P	Pierced primer at proof										
SCB-P	Stock cracked or broken at proof										
	and the state of proven at proof	L	I			 l	L	L	l		

Summary	_	Total Tested	598								
		Total Rejected:	25								
	Overa	all Reject Rate:	4.18						_		totals
	Droof	Shot: Rejected:	185 <i>0</i>	<u>3</u> 0	0	101 0	0	0	0	0	302 0
	Proof	Percent:	0.0	0.0	0.0	0.0	0.0	U	U	U	0.0
		Shot:	383	64	64	54	31	2			598
	Test	Rejected:	10	5	2	7	0	1	0	0	25
		Percent:	2.6	7.8	3.1	13.0	0.0	50.0			4.2
	- .	Shot:	37 0	7 0	0	6 0	0	22 0	0	0	81 0
	Target	Rejected: Percent:	0.0	0.0	0.0	0.0	0.0	0.0	U	U	0.0
CODE	MALFUNCTION	INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber										
BBMA	BBL-to-bolt misalignment										
BB	Bolt binds/catches		1								1
BCOAB	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
ВС	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch	h									
BLOP	Bar lock or disconnector	out of position									
BLSO	Barrel lug shot off										
ВРО	Bolt pulls out										
BSSM	Bolt stems shell in magaz	rine									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full r	magazine									
CD	Case dented										
СН	Closes hard										
CLM	Can't load magazine		2	1							3
СО	Cut-off										
CR	Cuts rim										
cs	Cases swell										

стос	Chamber torn or gouged							
СТР	Creepy trigger pull							
CWSB	Cams wrong side of action bar							
DBB	Doesn't blow back							
DCS	Double click in safety switch							
DCT	Double click in trigger							
DCU	Doesn't close-up							
DE	Doesn't eject							
DEL	Doesn't eject live round							
DFB	Doesn't feed back							
DFU	Doesn't feed up							
DLO	Doesn't lock open (after last shell)							
DLU	Doesn't lock-up							
DS	Dead safe							
DX	Doesn't extract		3					3
DXL	Doesn't extract live round							
EDS	Extractor drops shell				3	1		4
ESB	Ejector sticks back							
ESCR	Empty shell catches receiver							
ESS	Extractor stems shell							
FA	Fires automatically							
FB	Follower binds							
FC	Fails to connect							
FCB	Fore-end cracked or broken							
FD	Follows-down							
FF	Fails to fire							
FFP	Flat firing pin							
FOS	Fires on safe							
FPHB	Firing pin hits bbl							
FPHI	Firing pin hits inside rim							
FPO	Floor plate opens			2	1			3
FPOH	Floor plate opens hard							
FSR	Fires when safe is released							
FT	Follower tips	3						3
gcso	Gas cyl shot off							

HBL	Heavy bolt lift						
HMSC	Heading mismatch-steps on case						
НРА	High pressure ammo						
HUR	Hard under rail						
JCS	Jumps cartridge						
JM	Jumps magazine						
JO	Jars off						
LB	Light blow						
MAH	Magazine assembles hard						
MCW	Magazine capacity wrong						
MFA	Misfires (ammo)						
MFOP	Magazine follower out of position						
ML	Magazine loose						
MLH	Magazine loads hard						
MRH	Magazine removes hard						
ОН	Opens hard						
OR	Over-rides						
PH	Pulls hard						
PSI	Proof stamp illegible						
PSM	Proof stamp missing						
RBOC	Rings and bulges on case						
RDW	(Action) release doesn't work						
RIC	Rings in chamber						
RIS	Ring in sholder						
RS	Rim srem						
SBC	Stems bottom chambers	2					2
SBE	Stems bbl extension						
SCB	Stock cracked or broken						
scx	Shell catches						
SHI	Short indent						
SI	Stems incline	1					*
SIC	Stems in chamber			1			1
SL	shaves lead						
SLC	Stems left side of chamber						
SMOC	Stretch marks on case						

Stem over-ride									
Stems port									
Shoulder rough									
Stems right side of chamber									
Specific rings in chamber									
Surface scratches on case									
Stems top chamber									
Safety switch works too easily									
Safety switch works too hard				1					1
Safety Switch won't work									
Tips down									
Tips up									
Trigger won't pull									
Trigger won't retract									
Uncoded				1					3
Extracts hard	1	1							2
High									
Low									
Left									
Right									
Doesn't Group									
Front sight tipped									
Rear sight tipped									
Rear sight base raised									
Front sight raised									
Front sight loose									
Rear sight loose									
Missing parts at target									
Uncoded nonconformity at target									
Assembly incompleye at proof									
Barrel bracket cracked or broken at proof									
Blows cases at proof									
Barrel extension broken at proof									
	Stems port Shoulder rough Stems right side of chamber Specific rings in chamber Surface scratches on case Stems top chamber Safety switch works too easily Safety switch works too hard Safety Switch won't work Tips down Tips up Trigger won't retract Uncoded Extracts hard High Low Left Right Doesn't Group Front sight tipped Rear sight tipped Rear sight tose Front sight raised Front sight loose Rear sight loose Missing parts at target Uncoded nonconformity at target Assembly incompleye at proof Barrel bracket cracked or broken at proof Blows cases at proof	Stems port Shoulder rough Stems right side of chamber Specific rings in chamber Surface scratches on case Stems top chamber Safety switch works too easily Safety switch works too hard Safety Switch won't work Tips down Tips up Trigger won't pull Trigger won't retract Uncoded Extracts hard 1 High Low Left Right Doesn't Group Front sight tipped Rear sight base raised Front sight raised Front sight loose Rear sight loose Missing parts at target Uncoded nonconformity at target Assembly incompleye at proof Barrel bracket cracked or broken at proof Blows cases at proof	Stems port Shoulder rough Stems right side of chamber Specific rings in chamber Surface scratches on case Stems top chamber Safety switch works too easily Safety switch works too hard Safety Switch won't work Tips down Tips up Trigger won't pull Trigger won't retract Uncoded Extracts hard 1 1 1 High Low Left Right Doesn't Group Front sight tipped Rear sight base raised Front sight loose Rear sight loose Missing parts at target Uncoded nonconformity at target Barrel bracket cracked or broken at proof Blows cases at proof	Stems port Shoulder rough Stems right side of chamber Specific rings in chamber Surface scratches on case Stems top chamber Safety switch works too easily Safety switch works too hard Safety Switch won't work Tips down Tips up Trigger won't pull Trigger won't retract Uncoded Extracts hard 1 1 1 High Low Left Right Doesn't Group Front sight tipped Rear sight base raised Front sight raised Front sight raised Front sight loose Missing parts at target Uncoded nanconformity at target Assembly incompleye at proof Barrel bracket cracked or broken at proof Blows cases at proof	Stems port Shoulder rough Stems right side of chamber Specific rings in chamber Surface scratches on case Stems top chamber Safety switch works too easily Safety switch works too hard Safety switch work sto too hard 1 Safety Switch word work 1 Tips down 1 Tips up 1 Trigger won't pull 1 Trigger won't retract 1 Uncoded 1 Extracts hard 1 High 1 Low 1 Left 1 Right 1 Doesn't Group 1 Front sight tipped 1 Rear sight base raised 1 Front sight roise 1 Rear sight loose 1 Missing parts at target 1 Uncoded nonconformity at target 1 Assembly incompleye at proof 1 Barrel bracket cracked or broken at proof 1	Stems port Shoulder rough Image: Company of the compan	Stems port	Stems port Image: Company of the company	Stems port Image: Company of the company

DI D D	Diaminal mains and a mark					
BLP-P	Blanked primer at proof					
BLSO-P	Barrel lug shot off at proof					
BP-P	Blown primer at proof					
BS-P	Barrel split at proof					
DBF-P	Damaged Bolt Face					
DLOS-P	Doesn't lock over shells at proof					
ESBBP-P	Ejector sticks back -Blown Primer cup					
ESBEC-P	Ejector sticks back - Ejector Cresent					
FCB-P	Fore-end cracked at proof					
FESO-P	Fore-end shot off at proof					
FF-P	Fails to fire at proof					
GCSO-P	Gas cylinder shot off at proof					
MSI-P	Magnaflux stamp illegible on bbl					
MSM-P	Magnaflux stamp missing on bbl					
PP-P	Pierced primer at proof					
SCB-P	Stock cracked or broken at proof					
UNCM-P	Uncoded proof malfunctions					

C	T-117	de el	001								Teet Cata					
Summary	Total Tes Total Reject		664 60								Test Date:					
	Overall Reject R	ite: 9	.04													totals
		ot: 255		54	79	72	192		10							862
	Proof Reject Perc			0 0.0	0 0.0	0 0.0	0 0.0	0	0 0.0	0	0	0	0	0	0	3 0.5
		not: 211		147	164	2	124		16		1		ı		1	584
	Test Reject	ted: 21		7	14	0	11	0	4	0	0	0	0	0	0	57
	Perd			4.8	8.5	0.0	8.9		25.0							8.6
		not: 17 ted: 0		15 0	9 0	0	12 0	0	0	0	0			0	0	55 0
	Target Reject Perc			0.0	0.0	U	0.0	Ü	0.0	U	U	U	U	Ü	Ü	0.0
CODE	MALFUNCTION INDEX	700 SP	s 70	'00 SPS	700 BDL &	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
		+	_	SS	ADL							1				
AΒ	Action binds														1	
ABS	Bulge at body shoulder															
BAC	Burr at chamber	1														-3
BBMA	BBL-to-bolt misalignment															
ЗВ	Bolt binds/catches	1														1
BCOAB	Bolt catches on anti-bind															
BCOBS	Bolt catches on bolt stop					1							İ			
COF	Bolt catches on follower															
BC	Blows cases															
HR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
LOP	Bar lock or disconnector out of position	1														
BLSO	Barrel lug shot off															
PO .	Bolt pulls out															
SSM	Bolt stems shell in magazine															
WCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magazine			5												5
CD	Case dented															
CH	Closes hard				3				3							8
CLM	Can't load magazine			1												1
co	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
OBB	Doesn't blow back															
ocs	Double click in safety switch															
OCT	Double click in trigger															
OCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															
DFB	Doesn't feed back															
DFU	Doesn't feed up															
DLO	Doesn't lock open (after last shell)															
DLU	Doesn't lock-up															
DS	Dead safe															
DX	Doesn't extract	1			1		2									4
DXL	Doesn't extract live round															
EDS	Extractor drops shell	1					2									3

ESB	First stille basis			ı			ı	ı	1	1	ı	
	Ejector sticks back											
ESCR	Empty shell catches receiver											\vdash
ESS	Extractor stems shell											
FA	Fires automatically											
FB	Follower binds											
FC	Fails to connect											
FCB	Fore-end cracked or broken											
FD	Follows-down											
FF	Fails to fire											
FFP	Flat firing pin											
FOS	Fires on safe											
FPHB	Firing pin hits bbl											
FPHI	Firing pin hits inside rim											
FPO	Floor plate opens	3		5	1							9
FPOH	Floor plate opens hard											
FSR	Fires when safe is released											
FT	Follower tips											
GCSO	Gas cyl shot off											
HBL	Heavy bolt lift											
HMSC	Heading mismatch-steps on case											
HPA	High pressure ammo											
HUR	Hard under rail	7										T
JCS	Jumps cartridge											
JM	Jumps magazine					1						-3
JO	Jars off											
LB	Light blow											
MAH	Magazine assembles hard											
MCW	Magazine capacity wrong											
MFA	Misfires (ammo)											
MFOP	Magazine follower out of position											
ML	Magazine loose	6										ε
MLH	Magazine loads hard		1									1
MRH	Magazine removes hard											
ОН	Opens hard				2							2
OR	Over-rides			1								3
PH	Pulls hard											
PSI	Proof stamp illegible											
PSM	Proof stamp missing											
RBOC	Rings and bulges on case											
RDW	(Action) release doesn't work											
RIC	Rings in chamber	1										3
RIS	Ring in sholder											
RS	Rim srem											\vdash
SBC	Stems bottom chambers			1								1
SBE	Stems bbl extension											
SCB	Stock cracked or broken											
SCX	Shell catches											\vdash
SHI	Short indent											\vdash
SI	Stems incline				4				-			4
SIC					4							
SL	Stems in chamber											
	shaves lead											
SLC	Stems left side of chamber	1		<u> </u>		l	<u> </u>	l			<u> </u>	

	I	1	1	1	1	1	1		1	
SMOC	Stretch marks on case									
SOR	Stem over-ride									
SP	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber									
SRIC	Specific rings in chamber									
ssoc	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
sww	Safety Switch won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
XH	Extracts hard			3						3
ні	High									
LO	Low									
LEFT	Left									
RIGHT	Right									
DG	Doesn't Group									
FSST	Front sight tipped									
RSTT	Rear sight tipped									
RSBR	Rear sight base raised									
FSTR	Front sight raised									\vdash
FSTL	Front sight loose									\vdash
RSTL	Rear sight loose									\vdash
MGPT-G										
UNCN-G	Missing parts at target									-
UNCN-G	Uncoded nonconformity at target									-
41.5										—
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DBF-P	Damaged Bolt Face	3								3
DLOS-P	Doesn't lock over shells at proof									
ESBBP-P	Ejector sticks back -Blown Primer cup									
ESBEC-P	Ejector sticks back - Ejector Cresent									
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof									
SCB-P	Stock cracked or broken at proof									

Summary	Total Test + Proof		836								Test Date:					
	Total	Rejected:	13													
	Overall Re		1.56													fotals
	D 4	Shot:	507	124 0	16 0	36 0	33 0	67 0	6 0	0	0	0	0	0	0	783 2
	Proof	Rejected: Percent:	2 0.4	0.0	0.0	0.0	0.0	0.0	0.0	U	0	U	U	U	U	0.3
		Shot:	334	33	403	38		26								834
	Test	Rejected: Percent:	0 0.0	0 0.0	9 2.2	1 2.6	0	1 3.8	0	0	0	0	0	0	0	11 1.3
		Shot:	33	2	37	3		62								137
	Target	Rejected:	0 0.0	0 0.0	0 0.0	0 0.0	0	0 0.0	0	0	0	0	0	0	0	0 0.0
		Percent:		700 SPS	700 BDL &									1		5.6
CODE	MALFUNCTION INDE	X	700 SPS	SS	ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
ввма	BBL-to-bolt misalignment															
вв	Bolt binds/catches				3	1										4
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of	position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magaz	ine														
CD	Case dented															
СН	Closes hard				6											\$
CLM	Can't load magazine															
СО	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															
DFB	Doesn't feed back															
				•	•	•	•					•		•		

Gallery Performance Report

Proof - Test - Target

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
DFU	Doesn't feed up														
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up														
DS	Dead safe														
DX	Doesn't extract														
DXL	Doesn't extract live round														
EDS	Extractor drops shell														
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens														
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips														
gcso	Gas cyl shot off														
HBL	Heavy bolt lift														
HMSC	Heading mismatch-steps on case														
НРА	High pressure ammo														
HUR	Hard under rail														
JCS	Jumps cartridge														
JM	Jumps magazine														
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard														
OR	Over-rides														

Gallery Performance Report

Proof - Test - Target

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work						1								1
RIC	Rings in chamber														
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers														
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline														
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride														
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
ssoc	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard														
Н	High														
LO	Low														
LEFT	Left														
	Right														
DG	Doesn't Group														
FSST	Front sight tipped														
RSTT	Rear sight tipped														

Gallery Performance Report

Proof - Test - Target

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face	2													2
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup														
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions														

Summary	Total Test	ed 90	5							Test Date:					
ounnina y	Total Reject	ed: 3	1							rest Date.					
	Overall Reject Ra						_				_				totals
	Sh Proof Reject		1 44	144 0	148 0	43 0	0	0	0	0	0	0	0	0	884 2
	Perce	ent: 0.3	2.3	0.0	0.0	0.0	1 2								0.3 905
	Sh Test Reject		3	5	3	19	0	0	0	0	0	0	0	0	29
	Perce		2.1	2.5	4.4	5.3	0.0								3.2
	Sh		8	20	7	2	I								79
	Target Reject Perce		0 0.0	0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	0	0	0 0.0
CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
				ADE											
AΒ	Action binds														
BABS	Bulge at body shoulder														
BAC	Burr at chamber														
BBMA	BBL-to-bolt misalignment														
ВВ	Bolt binds/catches	1		1			1								2
BCOAB	Bolt catches on anti-bind						1								
BCOBS	Bolt catches on bolt stop						1								
COF	Bolt catches on follower						1								
c	Blows cases				ļ					ļ				ļ	
HR	Bolt hits receiver				ļ									ļ	
HS	Bolt plug hits safety switch						1								
LOP	Bar lock or disconnector out of position						1							ļ	
LSO PO	Barrel lug shot off				<u> </u>		+	<u> </u>		<u> </u>				<u> </u>	
SSM	Bolt pulls out				<u> </u>		+	<u> </u>		<u> </u>				<u> </u>	
WCD	Bolt stems shell in magazine Bolt won't cam down				-		+	1		1				 	
WCFM	Bolt won't close over full magazine						+								
D	Case dented				<u> </u>		+				1			1	
Н	Closes hard			2	<u> </u>		+				1				2
LM	Can't load magazine				<u> </u>		+	1		 				 	
0	Cut-off					1	+					-			
R	Cuts rim						1								
s	Cases swell						1								
TOG	Chamber torn or gouged														
TP	Creepy trigger pull														
CWSB	Cams wrong side of action bar					1	†								
DBB	Doesn't blow back		1				†								
ocs	Double click in safety switch														
ОСТ	Double click in trigger														
CU	Doesn't close-up														
ΡE	Doesn't eject														
EL	Doesn't eject live round														
)FB	Doesn't feed back														
FU	Doesn't feed up														
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up														
os	Dead safe														
ΟX	Doesn't extract	1	1												2
OXL	Doesn't extract live round														
DS	Extractor drops shell														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	intals
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens	1			1										ž
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips	5													5
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift														
HMSC	Heading mismatch-steps on case														
HPA	High pressure ammo														
HUR	Hard under rail	1		2											3
JCS	Jumps cartridge														
JM	Jumps magazine														
JO	Jars off														
LB	Light blow														
MAH	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard				1										1
ОН	Opens hard					1									1
OR	Over-rides	3													3
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber	1			1										2
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers														
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline														
SIC	Stems in chamber	4	2												6
SL	shaves lead	,													
<u> </u>	5.12.755 1020	<u> </u>			<u> </u>	I	1			<u> </u>					

Serve last value of controller	CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	intals
Sum near-faller Superior program Sum near-faller Superior program Sum near-faller prog	SLC	Stems left side of chamber														
Barris per	SMOC	Stretch marks on case														
### Smalake rough ### Committee #### Committee #### Committee #### Committee #### Committee #### Com	SOR	Stem over-ride														
Servicing set of analyses	SP	Stems port														
Service part of antener	SR	Shoulder rough														
Section for the management	SRC															
Section Sect																
Service Serv																
Series S																
Selection Sele																
SWY Safety South work																
To Tips to																
The Tips work part																
March Marc																
Type won't releast																
DICEAT Decoded																
Description																
III High LO Low LEFT Left With Significant Common C																
DC	хн	Extracts hard														
DC																
FEFT Left																
Digital Right Digital Digita																
Description	LEFT	Left														
RSTT Rear sight tipped RSTR Rear sight tipped RSTR Rear sight tipped RSTR Front sight ripped RSTR Rear sight loose RSTR Rear		Right														į
RSTR Rear sight lipped	DG	Doesn't Group														
RSSR Rear sight base raised	FSST	Front sight tipped														
FSTR Front sight raised FSTL Front sight loose MSPT-G Massing parts at target UNCN-G Uncoded nonconformity at target UNCN-G Uncoded nonconformity at target UNCN-G Uncoded nonconformity at target APP Assembly incompleye at proof BBB Barrel bracket cracked or broken at proof BC-P Blows cases at proof BC-P Blows cases at proof BC-P Blows cases at proof BC-P Blows faces at proof BC-P Blows faces at proof BC-P Barrel lug shot off at proof BC-P Barrel parts proof BC-P Blows primer at proof BC-P Blows prime	RSTT	Rear sight tipped														
FSTL Front sight loose RSTL Rear SIGHT REAR	RSBR	Rear sight base raised														
Rear sight loose	FSTR	Front sight raised														
RSTL Rear sight loose	FSTL	Front sight loose														
MSPT-G Missing parts at target UNCNG-Uncoded nonconformity at target U	RSTL															
UncN-G Uncoded nonconformity at target AHP Assembly incompleye at proof BBB Barrel bracket cracked or broken at proof BC-P Blows cases at proof BEB-P Barrel extension broken at proof BLP-P Blanked primer at proof BLP-P Blanked primer at proof BLSO-P Barrel lug shot off at proof BS-P Barrel spit at proof BS-P Blown primer at proof BS-P Barrel spit at proof BS-P Doesn't lock over shells at proof ESBBP-P Ejector sticks back - Ejector Cresent FCB-P Fore-end cracked at proof FF-P Fails to fire at proof MSI-P Magnaflux stamp illegible on bbi																
AI-P Assembly incompleye at proof	UNCN-G															
BBB Barrel bracket cracked or broken at proof BC-P Blows cases at proof BEB-P Barrel extension broken at proof BLP-P Blanked primer at proof BLSO-P Barrel lug shot off at proof BLSO-P Barrel lug shot off at proof BP-P Blown primer at proof BP-P Blown primer at proof BP-P Blown primer at proof BP-P Damaged Bolt Face 1 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2		, ,														
BBB Barrel bracket cracked or broken at proof BC-P Blows cases at proof BEB-P Barrel extension broken at proof BLP-P Blanked primer at proof BLSO-P Barrel lug shot off at proof BLSO-P Barrel lug shot off at proof BP-P Blown primer at proof BP-P Blown primer at proof BP-P Blown primer at proof BP-P Damaged Bolt Face 1 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	Al-P	Assembly incompleve at proof														
BCP Blows cases at proof Barrel extension broken at proof BLPP Blanked primer at proof BLSO-P Barrel lug shot off at proof BLSO-P Barrel lug shot off at proof BLSO-P Barrel split at proof BLSO-P Barrel split at proof Bar																
BEB-P Barrel extension broken at proof BLP-P Blanked primer at proof BLSO-P Barrel lug shot off at proof BP-P Blown primer at proof BS-P Barrel split at proof BS-P Barrel split at proof BS-P Damaged Bolt Face 1 1 1 DISS-P Doesn't lock over shells at proof ESBBP-P Ejector sticks back - Blown Primer cup ESBBP-P Ejector sticks back - Ejector Cresent FCB-P Fore-end cracked at proof FESO-P Fore-end shot off at proof FF-P Falls to fire at proof GCSO-P Gas cylinder shot off at proof MSI-P Magnafilux stamp illegible on bbl																
BLP-P Blanked primer at proof Barrel lug shot off at proof BLSO-P Barrel lug shot off at proof Blown primer at proof Blown primer at proof Barrel split at																
BLSO-P Barrel lug shot off at proof																
BP-P Blown primer at proof BS-P Barrel split at proof DBF-P Damaged Bolt Face 1 1 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2																
BS-P Barrel split at proof																
DBF-P Damaged Bolt Face 1 1 9 2 DLOS-P Doesn't lock over shells at proof 9								-								
DLOS-P Doesn't lock over shells at proof ESBBP-P Ejector sticks back - Blown Primer cup ESBEC-P Ejector sticks back - Ejector Cresent FCB-P Fore-end cracked at proof FESO-P Fore-end shot off at proof FF-P Fails to fire at proof GCSO-P Gas cylinder shot off at proof MSI-P Magnaflux stamp illegible on bbl																
ESBBP-P Ejector sticks back - Blown Primer cup ESBEC-P Ejector sticks back - Ejector Cresent FCB-P Fore-end cracked at proof FESC-P Fore-end shot off at proof FF-P Fails to fire at proof GCSO-P Gas cylinder shot off at proof MSI-P Magnaflux stamp illegible on bbl			1	1												5
ESBEC-P Ejector sticks back - Ejector Cresent																
FCB-P Fore-end cracked at proof																
FESO-P Fore-end shot off at proof																
FF-P Fails to fire at proof GCSO-P Gas cylinder shot off at proof MSI-P Magnaflux stamp illegible on bbl																
GCSO-P Gas cylinder shot off at proof MSI-P Magnaflux stamp illegible on bbl		Fore-end shot off at proof														
MSI-P Magnaflux stamp illegible on bbl	FF-P	Fails to fire at proof														
	GCSO-P	Gas cylinder shot off at proof														
	MSI-P	Magnaflux stamp illegible on bbl														
p p	MSM-P	Magnaflux stamp missing on bbl														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	intals
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions														

Summary	Total Teste	d 788								Test Date:					
Junina y	Total Rejected									rest Date.					
	Overall Reject Rate														totals
	Sho		43	2	139	44									853
	Proof Rejecte Percer	nt: 0.2	0 0.0	0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	0	0	† 0.1
	Sho Test Rejecte		105 2	53 0	82 0	0	0	0		<u> </u>	0	0	0	0	78% 15
	Test Rejecte Percer		1.9	0.0	0.0	U	U	v	Ü	v	U	v	U	U	1.9
	Sho		10	5	8										90
	Target Rejecte Percer		0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	0	0	0	0 0.0
		_	700 SPS	700 BDL &		700.001	700 801105		V	750	7400	7000	7045		1
ODE	MALFUNCTION INDEX	700 SPS	SS	ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	tofals
.B	Action binds														
ABS	Bulge at body shoulder	+	 								+		+		
AC AC	Burr at chamber														
BBMA	BBL-to-bolt misalignment		1	1											3
BB	Bolt binds/catches	1	-												1
COAB	Bolt catches on anti-bind														
COBS	Bolt catches on bolt stop			1											
COF	Bolt catches on follower														
С	Blows cases														
⊣R	Bolt hits receiver														
HS	Bolt plug hits safety switch														
.OP	Bar lock or disconnector out of position														
.SO	Barrel lug shot off														
0	Bolt pulls out														
SM	Bolt stems shell in magazine														
VCD	Bolt won't cam down														
NCFM	Bolt won't close over full magazine														
)	Case dented	1													1
Η	Closes hard														
LM	Can't load magazine	1		1											
:0	Cut-off	-													
R	Cuts rim	+		1							-		1		
S	Cases swell	1		1											
TOG	Chamber torn or gouged														
TP WSB	Creepy trigger pull		-	1		 							-	 	
)BB	Cams wrong side of action bar	+	-	1		 								-	
CS	Doesn't blow back Double click in safety switch	+	-	1		-								-	-
CT	Double click in safety switch		 	1		 					1				
CU	Doesn't close-up	+	 			-									
E	Doesn't eject														
EL	Doesn't eject live round	1	 	1											
FB	Doesn't feed back		 	1		 									
FU	Doesn't feed up														
LO	Doesn't lock open (after last shell)														
)LU	Doesn't lock-up														
os	Dead safe														
OX.	Doesn't extract														
OXL	Doesn't extract live round														
EDS	Extractor drops shell	1					1	İ		İ		İ			3

I	I=						ı			
ESB	Ejector sticks back									
ESCR	Empty shell catches receiver									
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FC	Fails to connect									
FCB	Fore-end cracked or broken									
FD	Follows-down									
FF	Fails to fire									
FFP	Flat firing pin									i
FOS	Fires on safe									ł
FPHB	Firing pin hits bbl									i
FPHI	Firing pin hits inside rim									
FPO	Floor plate opens	2								3
FPOH	Floor plate opens hard									
FSR	Fires when safe is released									
FT	Follower tips									
GCSO	Gas cyl shot off									
HBL	Heavy bolt lift									
HMSC	Heading mismatch-steps on case									
HPA	High pressure ammo									1
HUR	Hard under rail									i
JCS	Jumps cartridge									
JM	Jumps magazine									
JO	Jars off									
LB	Light blow	1								1
MAH	Magazine assembles hard									$\overline{}$
MCW	Magazine capacity wrong									
MFA	Misfires (ammo)									
MFOP	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard									
ОН	Opens hard									
OR	Over-rides	2	1							3
PH	Pulls hard		'							<u>_</u> _
PSI	Proof stamp illegible									
PSM	Proof stamp missing									
RBOC	Rings and bulges on case									
RDW	(Action) release doesn't work									
RIC	Rings in chamber	5								5
RIS		3								
RS	Ring in sholder									
	Rim srem	-								
SBC	Stems bottom chambers									\vdash
SBE	Stems bbl extension									\vdash
SCB	Stock cracked or broken									
	Shell catches									
SHI	Short indent									
SI	Stems incline									
	Stems in chamber									
SL	shaves lead									
SLC	Stems left side of chamber									

01100	lo	1	ı —	1		ı	1	I	1		ı	1	
	Stretch marks on case												
SOR	Stem over-ride												
SP	Stems port												
SR	Shoulder rough												
SRC	Stems right side of chamber												
SRIC	Specific rings in chamber												
ssoc	Surface scratches on case												
STC	Stems top chamber												
SWE	Safety switch works too easily												
SWH	Safety switch works too hard												
sww	Safety Switch won't work												
TD	Tips down												
TU	Tips up												
TWP	Trigger won't pull												
TWR	Trigger won't retract												
UNCN-T	Uncoded												
XH	Extracts hard												
HI	High												
LO	Low												
LEFT	Left												
RIGHT	Right												
DG	Doesn't Group												
FSST	Front sight tipped												
RSTT	Rear sight tipped												
RSBR	Rear sight base raised												
FSTR	Front sight raised												
FSTL	Front sight loose												
RSTL	Rear sight loose												
MGPT-G	Missing parts at target												
UNCN-G	Uncoded nonconformity at target												
Al-P	Assembly incompleye at proof												
BBB	Barrel bracket cracked or broken at proof												
BC-P	Blows cases at proof												
BEB-P	Barrel extension broken at proof												
BLP-P	Blanked primer at proof												
BLSO-P	Barrel lug shot off at proof												
BP-P	Blown primer at proof												
BS-P	Barrel split at proof												
DBF-P	Damaged Bolt Face												
DLOS-P	Doesn't lock over shells at proof												
ESBBP-P	Ejector sticks back -Blown Primer cup												
ESBEC-P	Ejector sticks back - Ejector Cresent												
FCB-P	Fore-end cracked at proof												
FESO-P	Fore-end shot off at proof												
FF-P	Fails to fire at proof	1											1
GCSO-P	Gas cylinder shot off at proof	'											
MSI-P	Magnaflux stamp illegible on bbl												
MSM-P	Magnaflux stamp missing on bbl												
PP-P	Pierced primer at proof												
SCB-P	Stock cracked or broken at proof												\vdash
00B-F	Stock cracked of broken at proof	L	l	L		l					l	L	

Summan	Total Tan	od 647	,							Toet Data:					
Summary	Total Tes Total Reject									Test Date:					
	Overall Reject Ra														totals
	Sh			94	295	218									864
	Proof Reject Perce	ent: 0.0	0	5 5.3	14 4.7	5 2.3	0	0	0	0	0	0	0	0	24 3.6
	Sh		0	271 4	138 3	198 3	10	0	0	0	0	0	0	0	617
	Test Reject Perce	ea: 0 ent:	U	1.5	2.2	1.5	100.0	U	U	U	U	U	Ü	U	20 3.2
	Sh			27	11	15									56
	Target Reject Perce		0	0 0.0	0 0.0	0 0.0	0	0	o	0	0	O	0	0	0 0.0
ODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	torals
3	Action binds														
ABS	Bulge at body shoulder														
BAC	Burr at chamber														
BBMA	BBL-to-bolt misalignment														
3B	Bolt binds/catches			3											3
BCOAB	Bolt catches on anti-bind		1		İ			İ							
COBS	Bolt catches on bolt stop														
COF	Bolt catches on follower														
С	Blows cases														
⊣R	Bolt hits receiver														
HS	Bolt plug hits safety switch														
.OP	Bar lock or disconnector out of position														
_SO	Barrel lug shot off														
0	Bolt pulls out														
SM	Bolt stems shell in magazine														
VCD	Bolt won't cam down														
VCFM	Bolt won't close over full magazine				1										1
)	Case dented														
4	Closes hard														
LM	Can't load magazine														
0	Cut-off														
R	Cuts rim														
s	Cases swell														
TOG	Chamber torn or gouged														
TP	Creepy trigger pull														
WSB	Cams wrong side of action bar														
BB	Doesn't blow back		1												
cs	Double click in safety switch														
СТ	Double click in trigger		1												
CU	Doesn't close-up														
E	Doesn't eject		1												
ΞL	Doesn't eject live round														
FB	Doesn't feed back		1												
FU	Doesn't feed up		1				1								
LO	Doesn't lock open (after last shell)		1												
DLU	Doesn't lock-up														
DS	Dead safe														
DΧ	Doesn't extract		1												
DXL EDS	Doesn't extract live round		1				1								
į.	Extractor drops shell														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens				1	1									2
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips														i
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift														
HMSC	Heading mismatch-steps on case														
HPA	High pressure ammo														
HUR	Hard under rail					2									2
JCS	Jumps cartridge														
JM	Jumps magazine														
JO	Jars off														
LB	Light blow														
MAH	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose						1								3
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard														
OR	Over-rides						3								3
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber	-													
RIS	Ring in sholder														-
RS	Rim srem	 													
SBC	Stems bottom chambers														-
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														\vdash
SI	Stems incline	<u> </u>													\vdash
SIC	Stems in chamber	-													\vdash
SL	shaves lead	-													\vdash
SL	Shaves lead	<u> </u>		<u> </u>	<u> </u>	l	İ		l	<u> </u>			l	<u> </u>	

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	intals
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride			1	1		6								13
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
ssoc	Surface scratches on case														
STC	Stems top chamber														i
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up						 								
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard														
XII	Extracts flaid														
HI	High														—
LO	Low														
LEFT	Left														\vdash
															\vdash
RIGHT	Right														\vdash
DG	Doesn't Group														\vdash
FSST	Front sight tipped														\vdash
RSTT	Rear sight tipped														\vdash
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose						ļ								\vdash
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face			5	12	4									21
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup				2	1									3
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														$\overline{}$
	I	I	I	<u> </u>	I	<u> </u>	1		I	I		I	I	<u> </u>	

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	intals
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions														i

Summary	Tota	l Tested	531								Test Date:					
,	Total R	ejected:	29													
	Overall Reje		5.46													totals
	Proof	Shot: Rejected:	187 6	32 0	235 0	64 0	0	0	25 0	0	0	0	0	0	0	549 6
		Percent: Shot:	3.2 365	0.0	0.0	0.0	0.0	25	0.0	ı				ı		1.1 531
	Test	Rejected:	12	0	0	1	0	9	0	0	0	0	0	0	0	22
		Percent:	3.3	0.0	0.0		0.0	36.0			_					4.1
	Target	Shot: Rejected:	37 0	7	0	0	0	15	0	0	0	0		0	0	66
		Percent:	0.0	0.0	0.0	•	0.0	6.7	•	•	•	•	-	•	•	1.5
CODE	MALFUNCTION INDEX	(700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
_																
AB	Action binds				+							ļ			<u> </u>	
BABS	Bulge at body shoulder				+							ļ			<u> </u>	
BAC BBMA	Burr at chamber BBL-to-bolt misalignment				-			-								
BBMA BB	Bolt binds/catches		1		+			+								1
BCOAB	Bolt catches on anti-bind		'		1			+								,
BCOBS	Bolt catches on bolt stop				+			+							 	
BCOF	Bolt catches on follower				+			+								
3C	Blows cases				1											
HR	Bolt hits receiver															
BHS	Bolt plug hits safety switch				†											
LOP	Bar lock or disconnector out of p	osition														
LSO	Barrel lug shot off															
PO	Bolt pulls out															
SSM	Bolt stems shell in magazine															
WCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magazii	ne														
D	Case dented															
CH	Closes hard															
CLM	Can't load magazine															
00	Cut-off															
CR	Cuts rim				1			-								
CS CTOG	Cases swell				1			1								
CTP	Chamber torn or gouged				1			1								
CWSB	Creepy trigger pull				+			+							-	
OBB OBB	Cams wrong side of action bar Doesn't blow back				+			+					-		-	
DCS	Double click in safety switch				+			+	1				 			
DCT	Double click in trigger				+			+	-							
CU	Doesn't close-up				+			+					 			
DE .	Doesn't eject															
DEL	Doesn't eject live round															
)FB	Doesn't feed back															
DFU	Doesn't feed up				1											
DLO	Doesn't lock open (after last she	II)			1											
DLU	Doesn't lock-up															
DS	Dead safe															
DX	Doesn't extract															
DXL	Doesn't extract live round															
EDS	Extractor drops shell															

505 I		1	1	1					I	1	
	Ejector sticks back										
ESCR	Empty shell catches receiver										
	Extractor stems shell										
	Fires automatically										
FB	Follower binds										
FC	Fails to connect										
FCB	Fore-end cracked or broken										
FD	Follows-down										
FF	Fails to fire										
	Flat firing pin										
	Fires on safe										
	Firing pin hits bbl										i
FPHI	Firing pin hits inside rim										i
	Floor plate opens										i
FPOH	Floor plate opens hard										i
FSR	Fires when safe is released										i
FT	Follower tips	2									2
GCSO	Gas cyl shot off										
HBL	Heavy bolt lift										
HMSC	Heading mismatch-steps on case										
HPA	High pressure ammo										
HUR	Hard under rail										
JCS	Jumps cartridge										
JM	Jumps magazine	2									2
JO	Jars off										
LB	Light blow										
МАН	Magazine assembles hard										
	Magazine capacity wrong										
	Misfires (ammo)										
MFOP	Magazine follower out of position										
	Magazine loose					7					y
	Magazine loads hard										
	Magazine removes hard					1					1
	Opens hard										
	Over-rides	7									7
	Pulls hard										
	Proof stamp illegible										
	Proof stamp missing										
	Rings and bulges on case										
	(Action) release doesn't work										
RIC	Rings in chamber										
	Ring in sholder										
-	Rim srem										
SBC	Stems bottom chambers				1						1
	Stems bbl extension				'						
						1					3
	Stock cracked or broken Shell catches					1					<u> </u>
SHI SI	Short indent										
	Stems incline										
	Stems in chamber										
SL	shaves lead										
SLC	Stems left side of chamber	İ									

01100	C	1	1	ı			ı	ı	ı	ı	ı	
	Stretch marks on case											
SOR	Stem over-ride											
	Stems port											
	Shoulder rough											
	Stems right side of chamber											
	Specific rings in chamber											
SSOC	Surface scratches on case											
	Stems top chamber											
SWE	Safety switch works too easily											
	Safety switch works too hard											
	Safety Switch won't work											
TD	Tips down											
TU	Tips up											
TWP	Trigger won't pull											
TWR	Trigger won't retract											
UNCN-T	Uncoded											
XH	Extracts hard											
HI	High											
LO	Low											
LEFT	Left											
RIGHT	Right											
	Doesn't Group					1						1
	Front sight tipped											
	Rear sight tipped											
	Rear sight base raised											
	Front sight raised											
	Front sight loose											
	Rear sight loose											
MGPT-G	Missing parts at target											
	Uncoded nonconformity at target											
	oncome noncome number											
Al-P	Assembly incompleye at proof											
	Barrel bracket cracked or broken at proof											
	Blows cases at proof											
	Barrel extension broken at proof											
	Blanked primer at proof											
	Barrel lug shot off at proof											
	Blown primer at proof											
	Barrel split at proof											
DBF-P		4										4
	Damaged Bolt Face Doesn't lock over shells at proof	+										-
	Ejector sticks back -Blown Primer cup											\vdash
	Ejector sticks back - Ejector Cresent											
	Fore-end cracked at proof											
FESO-P	Fore-end shot off at proof											
	Fails to fire at proof											
	Gas cylinder shot off at proof											
	Magnaflux stamp illegible on bbl											
	Magnaflux stamp missing on bbl	2										ž
PP-P	Pierced primer at proof											
SCB-P	Stock cracked or broken at proof											

Summary		Total Tested Total Rejected: all Reject Rate:	523 55 10.52								<i>totals</i>
		Shot:	380	125		26					531
	Proof	Rejected: Percent:	1 0.3	0 0.0	0	0 0.0	0	0	0	0	1 0.2
		Shot:	96	137	234	55		1			523
	Test	Rejected: Percent:	12 12.5	5 3.6	37 15.8	0 0.0	0	0 0.0	0	0	54 10.3
		Shot:	10	13	23	6		1			53
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0	0 0.0	0	0	0 0.0
CODE	MALFUNCTIO	N INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber										
ВВМА	BBL-to-bolt misalignment	t									
ВВ	Bolt binds/catches			1	1						2
ВСОАВ	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
BC	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch	ch									
BLOP	Bar lock or disconnector	out of position									
BLSO	Barrel lug shot off										
вро	Bolt pulls out										
BSSM	Bolt stems shell in magaz	zine									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full	magazine			1						1
CD	Case dented										
СН	Closes hard										
CLM	Can't load magazine										
СО	Cut-off										
CR	Cuts rim										
cs	Cases swell										

	T					
CTOG	Chamber torn or gouged					
СТР	Creepy trigger pull					
CWSB	Cams wrong side of action bar					
DBB	Doesn't blow back					
DCS	Double click in safety switch					
DCT	Double click in trigger					
DCU	Doesn't close-up					
DE	Doesn't eject					
DEL	Doesn't eject live round					
DFB	Doesn't feed back					
DFU	Doesn't feed up					
DLO	Doesn't lock open (after last shell)					
DLU	Doesn't lock-up					
DS	Dead safe					
DX	Doesn't extract					
DXL	Doesn't extract live round					
EDS	Extractor drops shell	1	1			2
ESB	Ejector sticks back					
ESCR	Empty shell catches receiver					
ESS	Extractor stems shell					
FA	Fires automatically					
FB	Follower binds					
FC	Fails to connect					
FCB	Fore-end cracked or broken					
FD	Follows-down					
FF	Fails to fire					
FFP	Flat firing pin					
FOS	Fires on safe					
FPHB	Firing pin hits bbl					
FPHI	Firing pin hits inside rim					
FPO	Floor plate opens					
FPOH	Floor plate opens hard					
FSR	Fires when safe is released					
FT	Follower tips					
gcso	Gas cyl shot off					

				1	1	1	1	
HBL	Heavy bolt lift							
нмѕс	Heading mismatch-steps on case							
HPA	High pressure ammo							
HUR	Hard under rail							
JCS	Jumps cartridge							
JM	Jumps magazine			17				17
JO	Jars off							
LB	Light blow							
MAH	Magazine assembles hard							
MCW	Magazine capacity wrong							
MFA	Misfires (ammo)							
MFOP	Magazine follower out of position							
ML	Magazine loose							
MLH	Magazine loads hard							
MRH	Magazine removes hard							
ОН	Opens hard		1					3
OR	Over-rides	12						12
PH	Pulls hard							
PSI	Proof stamp illegible							
PSM	Proof stamp missing							
RBOC	Rings and bulges on case							
RDW	(Action) release doesn't work							
RIC	Rings in chamber							
RIS	Ring in sholder							
RS	Rim srem							
SBC	Stems bottom chambers		1	15				16
SBE	Stems bbl extension							
SCB	Stock cracked or broken							
scx	Shell catches							
SHI	Short indent							
SI	Stems incline							
sic	Stems in chamber							
SL	shaves lead							
SLC	Stems left side of chamber							
smoc	Stretch marks on case							

SOR	Stem over-ride	1	1			2
SP	Stems port					
SR	Shoulder rough					
SRC	Stems right side of chamber					
SRIC	Specific rings in chamber					
ssoc	Surface scratches on case					
STC	Stems top chamber					
SWE	Safety switch works too easily					
SWH	Safety switch works too hard					
sww	Safety Switch won't work					
TD	Tips down					
TU	Tips up					
TWP	Trigger won't pull					
TWR	Trigger won't retract					
UNCN-T	Uncoded					
ХН	Extracts hard		1			1
НІ	High					
LO	Low					
LEFT	Left					
RIGHT	Right					
DG	Doesn't Group					
FSST	Front sight tipped					
RSTT	Rear sight tipped					
RSBR	Rear sight base raised					
FSTR	Front sight raised					
FSTL	Front sight loose					
RSTL	Rear sight loose					
MGPT-G	Missing parts at target					
UNCN-G	Uncoded nonconformity at target					
AI-P	Assembly incompleye at proof					
BBB	Barrel bracket cracked or broken at proof					
BC-P	Blows cases at proof					
BEB-P	Barrel extension broken at proof					

BLP-P	Blanked primer at proof							
BLSO-P	Barrel lug shot off at proof							
BP-P	Blown primer at proof							
BS-P	Barrel split at proof							
DBF-P	Damaged Bolt Face	1						1
DLOS-P	Doesn't lock over shells at proof							
ESBBP-P	Ejector sticks back -Blown Primer cup							
ESBEC-P	Ejector sticks back - Ejector Cresent							
FCB-P	Fore-end cracked at proof							
FESO-P	Fore-end shot off at proof							
FF-P	Fails to fire at proof							
GCSO-P	Gas cylinder shot off at proof							
MSI-P	Magnaflux stamp illegible on bbl							
MSM-P	Magnaflux stamp missing on bbl							
PP-P	Pierced primer at proof							
SCB-P	Stock cracked or broken at proof							
UNCM-P	Uncoded proof malfunctions		_	_		_		
	•							

Summary		Total Tested otal Rejected: Il Reject Rate:	167 10 5.99								totals
		Shot:	51	8	24	5	36	17			141
	Proof	Rejected:	0	0	0	0	3	0	0	0	3
		Percent:	0.0	0.0	0.0	0.0	8.3	0.0			2.1
	Test	Shot: [Rejected:	44 0	0	55 3	2 0	55 2	11 2	0	0	167 7
	rest	Percent:	0.0	Ŭ	5.5	0.0	3.6	18.2	Ŭ	Ü	4.2
		Shot:	4		6		6				16
	Target	Rejected: Percent:	0 0.0	0	0 0.0	0	0 0.0	0	0	0	0 0.0
CODE	MALFUNCTION	INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber										
ВВМА	BBL-to-bolt misalignment										
ВВ	Bolt binds/catches										
ВСОАВ	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
вс	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch										
BLOP	Bar lock or disconnector or	ut of position									
BLSO	Barrel lug shot off										
вро	Bolt pulls out										
BSSM	Bolt stems shell in magazir	ne									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full m	agazine									
CD	Case dented										
сн	Closes hard										
CLM	Can't load magazine										
со	Cut-off										
CR	Cuts rim										
cs	Cases swell										

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
стос	Chamber torn or gouged									
СТР	Creepy trigger pull									
CWSB	Cams wrong side of action bar									
DBB	Doesn't blow back									
DCS	Double click in safety switch									
DCT	Double click in trigger									
DCU	Doesn't close-up									
DE	Doesn't eject									
DEL	Doesn't eject live round									
DFB	Doesn't feed back									
DFU	Doesn't feed up									
DLO	Doesn't lock open (after last shell)									
DLU	Doesn't lock-up									
DS	Dead safe									
DX	Doesn't extract									
DXL	Doesn't extract live round									
EDS	Extractor drops shell									
ESB	Ejector sticks back									
ESCR	Empty shell catches receiver									
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FC	Fails to connect									
FCB	Fore-end cracked or broken									
FD	Follows-down									
FF	Fails to fire									
FFP	Flat firing pin									
FOS	Fires on safe									
FPHB	Firing pin hits bbl									
FPHI	Firing pin hits inside rim									
FPO	Floor plate opens			1						1
FPOH	Floor plate opens hard									
FSR	Fires when safe is released									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
FT	Follower tips									
GCSO	Gas cyl shot off									
HBL	Heavy bolt lift									
HMSC	Heading mismatch-steps on case									
HPA	High pressure ammo									
HUR	Hard under rail									
JCS	Jumps cartridge									
JM	Jumps magazine									
JO	Jars off									
LB	Light blow									
MAH	Magazine assembles hard									
MCW	Magazine capacity wrong									
MFA	Misfires (ammo)									
MFOP	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard									
ОН	Opens hard						1			3
OR	Over-rides			1						1
PH	Pulls hard									
PSI	Proof stamp illegible									
PSM	Proof stamp missing									
RBOC	Rings and bulges on case									
RDW	(Action) release doesn't work									
RIC	Rings in chamber									
RIS	Ring in sholder									
RS	Rim srem									
SBC	Stems bottom chambers									
SBE	Stems bbl extension									
SCB	Stock cracked or broken									
scx	Shell catches									
SHI	Short indent									
SI	Stems incline									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
sic	Stems in chamber									
SL	shaves lead									
SLC	Stems left side of chamber									
SMOC	Stretch marks on case									
SOR	Stem over-ride									
SP	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber									
SRIC	Specific rings in chamber									
ssoc	Surface scratches on case									
STC	Stems top chamber			1						1
SWE	Safety switch works too easily									
swн	Safety switch works too hard									
sww	Safety Switch won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
хн	Extracts hard					2	1			3
н	High									
LO	Low									
LEFT	Left									
RIGHT	Right									
DG	Doesn't Group									
FSST	Front sight tipped									
RSTT	Rear sight tipped									
RSBR	Rear sight base raised									
FSTR	Front sight raised									
FSTL	Front sight loose									
RSTL	Rear sight loose									
MGPT-G	Missing parts at target									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DBF-P	Damaged Bolt Face									
DLOS-P	Doesn't lock over shells at proof									
ESBBP-P	Ejector sticks back -Blown Primer cup									
ESBEC-P	Ejector sticks back - Ejector Cresent									
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof					3				3
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl			_						
PP-P	Pierced primer at proof			_					_	
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions									

Summary		Total Tested	897								
		otal Rejected:	27								
	Overa	II Reject Rate:	3.01								totals
	Droof	Shot: [Rejected:	715 <i>0</i>	57 0	69 0	0	32 0	20 0	0	0	897 0
	Proof	Percent:	0.0	0.0	0.0	0.0	0.0	0.0	U	U	0.0
		Shot:	680	58	109		30	20		1	897
	Test	Rejected:	19	0	4	0	0	3	0	0	26
		Percent:	2.8	0.0	3.7		0.0	15.0			2.9
	T	Shot: [Rejected:	67 1	6 0	12 0	0	0	0	0	0	88 1
	Target	Percent:	1.5	0.0	0.0	Ū	Ŭ	0.0	Ŭ	Ŭ	1.1
CODE	MALFUNCTION	INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
АВ	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber							1			1
ВВМА	BBL-to-bolt misalignment										
ВВ	Bolt binds/catches				1			1			2
ВСОАВ	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
ВС	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch	ı									
BLOP	Bar lock or disconnector of	out of position									
BLSO	Barrel lug shot off										
вро	Bolt pulls out										
BSSM	Bolt stems shell in magazi	ine									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full n	nagazine	1								1
CD	Case dented										
СН	Closes hard										
СГМ	Can't load magazine		1								1
СО	Cut-off										
CR	Cuts rim										
cs	Cases swell										

стос	Chamber torn or gouged					
СТР	Creepy trigger pull					
CWSB	Cams wrong side of action bar					
DBB	Doesn't blow back					
DCS	Double click in safety switch					
DCT	Double click in trigger					
DCU	Doesn't close-up					
DE	Doesn't eject					
DEL	Doesn't eject live round					
DFB	Doesn't feed back					
DFU	Doesn't feed up					
DLO	Doesn't lock open (after last shell)					
DLU	Doesn't lock-up					
DS	Dead safe					
DX	Doesn't extract	2				2
DXL	Doesn't extract live round					
EDS	Extractor drops shell					
ESB	Ejector sticks back					
ESCR	Empty shell catches receiver					
ESS	Extractor stems shell					
FA	Fires automatically					
FB	Follower binds					
FC	Fails to connect					
FCB	Fore-end cracked or broken					
FD	Follows-down					
FF	Fails to fire					
FFP	Flat firing pin					
FOS	Fires on safe					
FPHB	Firing pin hits bbl					
FPHI	Firing pin hits inside rim					
FPO	Floor plate opens	1				1
FPOH	Floor plate opens hard					
FSR	Fires when safe is released					
FT	Follower tips	6	1			7
GCSO	Gas cyl shot off					

HBL	Heavy bolt lift						
HMSC	Heading mismatch-steps on case						
НРА	High pressure ammo						
HUR	Hard under rail				1		1
JCS	Jumps cartridge						
JM	Jumps magazine						
JO	Jars off						
LB	Light blow						
MAH	Magazine assembles hard						
MCW	Magazine capacity wrong						
MFA	Misfires (ammo)						
MFOP	Magazine follower out of position						
ML	Magazine loose						
MLH	Magazine loads hard						
MRH	Magazine removes hard						
ОН	Opens hard						
OR	Over-rides		1				1
PH	Pulls hard						
PSI	Proof stamp illegible						
PSM	Proof stamp missing						
RBOC	Rings and bulges on case						
RDW	(Action) release doesn't work						
RIC	Rings in chamber						
RIS	Ring in sholder						
RS	Rim srem						
SBC	Stems bottom chambers	3					3
SBE	Stems bbl extension						
SCB	Stock cracked or broken						
scx	Shell catches						
SHI	Short indent						
SI	Stems incline						
SIC	Stems in chamber						
SL	shaves lead						
SLC	Stems left side of chamber						
SMOC	Stretch marks on case						

SOR	Stem over-ride	4	1			ő
SP	Stems port	•	<u> </u>			-
SR	Shoulder rough		<u> </u>			
SRC	Stems right side of chamber		<u> </u>			
SRIC	Specific rings in chamber					
ssoc	Surface scratches on case					
STC	Stems top chamber					
SWE	Safety switch works too easily					
swh	Safety switch works too hard					
sww	Safety Switch won't work					
TD	Tips down					
TU	Tips up					
TWP	Trigger won't pull					
TWR	Trigger won't retract					
UNCN-T	Uncoded					
хн	Extracts hard	1				1
НІ	High					
LO	Low					
LEFT	Left					
RIGHT	Right					
DG	Doesn't Group					
FSST	Front sight tipped					
RSTT	Rear sight tipped					
RSBR	Rear sight base raised					
FSTR	Front sight raised					
FSTL	Front sight loose					
RSTL	Rear sight loose					
MGPT-G	Missing parts at target					
UNCN-G	Uncoded nonconformity at target	1				*
AI-P	Assembly incompleye at proof					
ввв	Barrel bracket cracked or broken at proof					
BC-P	Blows cases at proof					
BEB-P	Barrel extension broken at proof					

DI D D	Diaminal mains and a mark					
BLP-P	Blanked primer at proof					
BLSO-P	Barrel lug shot off at proof					
BP-P	Blown primer at proof					
BS-P	Barrel split at proof					
DBF-P	Damaged Bolt Face					
DLOS-P	Doesn't lock over shells at proof					
ESBBP-P	Ejector sticks back -Blown Primer cup					
ESBEC-P	Ejector sticks back - Ejector Cresent					
FCB-P	Fore-end cracked at proof					
FESO-P	Fore-end shot off at proof					
FF-P	Fails to fire at proof					
GCSO-P	Gas cylinder shot off at proof					
MSI-P	Magnaflux stamp illegible on bbl					
MSM-P	Magnaflux stamp missing on bbl					
PP-P	Pierced primer at proof					
SCB-P	Stock cracked or broken at proof					
UNCM-P	Uncoded proof malfunctions					