

Reading page 7 of the owner's manual, implies that the safety mechanism is to ...

Discussion Thread

Response (Denis)

10/4/2002 8:58:54 AM

Dear George, we apologize for any misunderstanding or confusion with our owner's manual. All attempts are made to make them as user friendly as possible. The bolt must be in the "cocked" position prior to moving the safety to the on position. You may raise the bolt, then cam it down and apply the safety this way also.

Customer (george kailas)

9/30/2002 11:31:14 AM

Reading page 7 of the owner's manual, implies that the safety mechanism is to be applied before handling, loading or unloading the rifle. However, the safety switch can't be engaged until the bolt has been raised, pulled back, and then pushed forward and locked. This means the trigger is cocked with or without a round in the chamber. Your manual implies otherwise.

Please explain.