Subject:

Remington Arms Co., Inc.
Bolt Action Centerfire Safety Modification Program

Notice of Change in Operation: Non-Bolt Lock Centerfire Firearms:

Due to the changes made to your Remington firearm, it will no longer be necessary for you to put the safety in the "F" or "Fire" position to load and unload the rifle. Your rifle can be loaded and unloaded while the safety is kept in the "S" or "Safe" position.

However, you must still follow the 10 Commandments of Firearms Safety in handling your firearm. Always keep the muzzle of any firearm pointed in a safe direction, especially when you are loading or unloading. Keep the safety in the "S" or "Safe" position at all times until you are actually ready to shoot. Always unload your firearm when not in use. Always unload your firearm as soon as you have finished shooting before taking it into your car, camp or home. For further information on firearms safety visit the Remington Safety Center at www.remington.com