

Remington®

Repair Form

(NOTE: Please print and complete this form, and then include it with your firearm.)

Model Number: <i>Mohawk-600</i>		Serial Number: <i>6430889</i>	
Name: <i>RONALD IBARRA</i>		Date of Purchase: <i>1972</i>	
Address (no PO Boxes): <i>4677 LILY AVENUE NORTH</i>			
City: <i>LAKE ELMO</i>		State: <i>MN</i>	Zip: <i>55042</i>
Phone (Daytime): <i>651-351-7665</i>		Fax: <i>—</i>	
E-mail Address: <i>RGARCIA111@MSN.COM</i>			
Please describe your problem:			
<i>1. WHEN UNLOADING WEAPON, SAFE OFF, WEAPON MAY DISCHARGE WITHOUT PULLING TRIGGER</i>			
<i>2. WHEN SHOOTING AT GAME, SAFE OFF WEAPON MAY DISCHARGE WHILE CHAMBERING NEW SHELL FOR MULTIPLE SHOTS</i>			
Additional Information: (Ammo type, brand, handload specifications, etc.)			
<i>PLEASE DO NOT INCREASE TRIGGER LBS OF PULL</i>			
NOTE: Prior to shipping your firearm, contact the Repair Center for services provided and estimated repair time.			
<p>⚠ WARNING: DO NOT SEND LIVE OR SPENT SHELLS IN YOUR FIREARM OR IN THE SAME BOX WITH THE FIREARM. THIS IS A VIOLATION OF FEDERAL LAW. IF YOU FEEL YOU MUST SEND SPENT SHELLS PLEASE SEND THEM IN A SEPARATE PACKAGE AND INCLUDE NAME, ADDRESS (WITH ZIP CODE), TELEPHONE AND MODEL AND SERIAL NUMBER OF YOUR FIREARM.</p> <p>:: Record the serial number of your firearm before sending it. :: Pack your firearm for safety and to prevent further damage in shipping and handling. Preferably, ship in a firearm box. (Note: Original boxes may not be returned.) :: Remove all accessories from your firearm to prevent loss or damage. :: Ship your INSURED firearm by either UPS or Parcel Post. Remington is not responsible for damage or loss during shipment, so you may elect to purchase insurance from your carrier.</p>			

