Bolt Action Centerfire – Bolt Lock Safety Modification Program Website text

Remington is offering a safety modification program to remove the bolt-lock mechanism from certain Remington bolt-action centerfire firearms made prior to March, 1982. (Post-1982 bolt-action firearms were not manufactured with bolt-lock mechanisms). To determine whether your firearm has a bolt-lock mechanism and is subject to the safety modification program, "click" on the model listed below and follow the directions included.

The unloading process for most bolt-action firearms with a bolt-lock mechanism cannot begin unless the manual safety is placed in the 'F" or "Off or Fire" position. If you participate in the program your firearm will be modified to eliminate the bolt-lock feature and you will be able to unload your firearm while the safety is kept in the "S" or "On Safe" position. The operation of your firearm will not otherwise be affected.

Here are the basic program elements:

- The firearms will be cleaned and inspected and the bolt lock mechanism will be removed for \$20.00 plus shipping and handling.
- We will return the gun to you with a \$20.00 rebate coupon good towards the purchase of any Remington brand safety product (eye protection, hearing protection, cable and trigger locks, gun cabinets and gun safes.)

Please click on the centerfire model listed below to obtain more information on the program for the specific model, as there are some differences in the program based on model type:

- Insert picture of Model 700
- Insert picture of Model 600
- Insert picture of Model 660
- Insert picture of Model 721
- Insert picture of Model 722
- Insert picture of Model 725
- Insert picture of Model 788
- Insert picture of Model XP-100
- Insert picture of Model 40-X
- Insert picture of Model Seven
- Insert picture of Model 710
- Insert picture of Model 30, 30 Express

If you have a bolt-action rifle with a bolt-lock mechanism, and you do not wish to have the lock removed, you must be sure to follow this IMPORTANT SAFETY NOTICE: Be sure the rifle is pointing in a safe direction anytime you move the manual safety to the "F" or "Off or Fire" position. As soon as you have lifted the bolt, immediately put the manual safety back in the "S" or "On Safe" position and then continue the unloading process.