

Dwg. No.		No. REQ.	NAME
PRE-FIX	PART NO.		
D	17000 YT	1	BARREL ASSEMBLY
D	17001 T	1	Barrel, 24"
A	17002	1	Barrel Bracket
A	17563 W	1	Bracing Shim
B	17003	1	Front Sight Ramp
D	17004 V	1	Receiver
N	17255 YB	1	BOLT FINAL ASSEMBLY
O	17005 YB	1	BOLT ASSEMBLY
N	17224 YU	1	BOLT BODY ASSEMBLY
E	17006 Y	1	Bolt Body
E	17007 Y	1	Bolt Head
A	17565 W	1	Bracing Ring
A	17011	1	Ejector Washer
N	17222 Y	1	BOLT HANDLE ASSEMBLY
C	17007	1	Bolt Handle
A	17008	1	Bolt Handle Ball
A	17564 W	1	Bracing Slug
A	17563 V	1	Bracing Shim
A	17017	1	Ejector
A	17018	1	Ejector Pin
A	17019	1	Ejector Spring
2G	17020 W	1	Extractor (Blank Dwg. 1B-17020-W)
N	17223 YV	1	FIRING PIN ASSEMBLY
C	17012	1	Bolt Plug
B	17021 V	1	Firing Pin
A	17022	1	Firing Pin Cross Pin
B	17023	1	Firing Pin Head (Blank Dwg. A-17113)
A	17058	1	Main Spring
B	17013	1	Bolt Stop
A	17014	1	Bolt Stop Spring
C	17015	1	Butt Plate
B	17016	2	Butt Plate Screw
A	17580	1	Center Guard Screw
C	17116 Y	1	FOLLOWER ASSEMBLY
C	17056	1	Follower
C	17028 V	1	Magazine Spring
A	17025 U	1	Front Guard Screw
B	17026	1	Front Sight
C	17057	1	Magazine
B	17030 Y	1	OPEN SIGHT ASSEMBLY
A	17031	1	Open Sight Base
B	17032	1	Open Sight Leaf
B	17033 W	1	Open Sight Stop
A	17025 V	1	Rear Guard Screw
A	17034	1	Receiver Plug Screw
D	17035 V	1	Stock (Blank Dwg. D-17069)

SERIAL No.		MODEL 722 - BASIC		PAGE 1	
STARTING	ENDING				
D	17036 Y	1	TRIGGER ASSEMBLY		
A	17037 W	1	Bolt Stop Pin		
B	17038	1	Bolt Stop Release		
C	17039	1	Housing		
C	17040	1	Safety		
A	17041	1	Safety Detent Ball		
A	17042	1	Safety Detent Spring		
A	17043	1	Safety Pivot Pin		
A	17044	1	Safety Snap Washer		
B	17045	1	Sear		
A	17037 V	1	Sear Pin		
A	17047	1	Sear Spring		
C	17048	1	Trigger		
A	17049	2	Trigger Adjusting Screw		
A	17050	1	Trigger Connector		
A	17037 U	1	Trigger Pin		
A	17047	1	Trigger Spring		
A	17053	1	Trigger Stop Screw		
O	17054 V	1	Trigger Guard		
B	17055	1	Trigger Guide Plate		