

DATE		MODEL 700 RIFLE						270 LH	
10-21-71		Bolt Action Repeater Center Fire			17 Rem.	25-06		7mm LH	
12-27-72		RIGHT HAND and LEFT HAND (LH)		222	222	222	25-06	30-06 LH	
				308	308	223	270	25-06	
				243	243	243	30-06	300M	
				6mm	6mm	6mm	7mm	270	
				22-250	22-250	22-250		30-06	
								7mm	
								264	7.62
SHEET OF	9	Dotted line (- - - -) indicates same part number.							
DWG. NO.		PART NUMBER Name	ADL Short	BDL Short	BDL Varm.	ADL Long	BDL Long	BDL MSR	
PART NUMBERS									
A-18186		Stock Reinforcing Screw	18186	----	----	----	----	----	
C-25410		Recoil Pad Screw (2)				25410	----	----	
		(See Recoil Pad for caliber use)							
		Stock							
E-26390		All Calibers	26390						
E-26390		270, 30-06, 25-06				26391			
E-26390		7mm				26395			
E-26410		222, 243, 308, 6mm, 22-250, 17 Rem.		26410					
E-26410		270, 30-06, 25-06					26411		
E-26410		7mm, 264, 300 Win. Mag.					26412		
D-26413		All Calibers			26413				
D-16865		7.62 Nato							16865
D-26413		25-06 (Long Action)			26414				
D-32925		Stock 30-06, 270 LH					32926		
"		7mm LH					32927		
1-2D-32920		Stock (All Calibers) (ADL) (Reference ONLY)							
A-26555		SWIVEL ASSEMBLY (2)		26555	----		26555		
A-15365		Swivel Screw, Front		15356	----		15356		
A-15358		Swivel Screw, Rear		15358	----		15358	----	
D-26345		TRIGGER ASSEMBLY (New Style)	26345	----	----	----	----	----	
D-32895		TRIGGER ASSEMBLY LH						32895	
C-15478		Bolt Stop Release	15478	----	----	----	----	----	
C-90555		Bolt Stop Release LH						90555	
B-26585		SAFETY ASSEMBLY	26585	----	----	----	----	----	
B-32900		SAFETY ASSEMBLY LH						32900	
C-15370		Safety	15370	----	----	----	----	----	
C-90556		Safety LH						90556	
C-14578		Safety Button	14578	----	----	----	----	----	
B-23220		Safety Detent Ball	23222	----	----	----	----	----	
B-15368		Safety Detent Spring	15368	----	----	----	----	----	
B-90557		Safety Detent Spring LH						90557	
B-17043		Safety Pivot Pin	17043	----	----	----	----	----	
A-17044		Safety Snap Washer	17044	----	----	----	----	----	
C-15666		Sear Safety Cam	15666	----	----	----	----	----	
A-17047		Sear Spring	17047	----	----	----	----	----	
C-15280		Trigger	15280	----	----	----	----	----	
B-17053		Trigger Adjusting Screw	17053	----	----	----	----	----	
B-19461		Trigger Connector	19461	----	----	----	----	----	