

Bolt/Firing Pin

The major components found in this assembly are as follows:

- Bolt Plug (P)
- Firing Pin (F)
- Firing Pin Head and Retaining Pin (FH)
- Firing Pin Spring (S)
- Bolt Head (BH)
- Bolt Body (B)
- Bolt Handle and Cocking Cam (H)

The components of this assembly, including pins, ejector, and extractor parts, number sixteen. (Photo #3)

