
Magazine Box

This assembly contains a hinged floor plate that the magazine box attaches to. The floor plate is latched into position by a button and spring in the front of the separate trigger guard.



The magazine can be removed from the floor plate and is a single contained init. The magazine disassembles into five main parts. (Photo #9)

- Magazine Box (B)
- Follower (F)
- Magazine Spring (S)
- Magazine Bottom Plate (P)
- Magazine Insert (in front) (I)