

## TO LOAD THE FIREARM

### I TO LOAD THE MAGAZINE AND CHAMBER:

1. Point the firearm in a safe direction.
2. Put the safety switch in the "F" position.
3. Raise the bolt handle.
4. Put the safety switch in the "S" position.
5. Pull the bolt handle all the way back.
6. Push four cartridges of the correct caliber, one at a time into the magazine. If the firearm is a magnum, you only load three cartridges. Keep the bullets aligned toward the chamber. See picture 6.
7. Put one cartridge into the chamber.
8. Use your fingers to push the cartridges in the magazine all the way down. Slowly slide the bolt assembly forward, so that the bolt slides over the top of the cartridges in the magazine.
9. Push the bolt handle down.

THE FIREARM IS NOW LOADED.

10. To fire the firearm put the safety switch in the "F" position.

THE FIREARM IS READY TO FIRE.

### II TO LOAD ONE CARTRIDGE ONLY:

1. Point the firearm in a safe direction.
2. Put the safety switch in the "F" position.
3. Raise the bolt handle.
4. Put the safety switch in the "S" position.

5. Pull the bolt handle all the way back.
6. Put one cartridge of the correct caliber on the magazine follower, or in the chamber. See picture 6.
7. Slide the bolt handle forward, then push the bolt handle down to lock the cartridge into the chamber.

THE FIREARM IS NOW LOADED.

8. To fire the firearm put the safety switch in the "F" position.

THE FIREARM IS READY TO FIRE.

**WARNING:** Always check the cartridge for the correct caliber before loading the firearm.

