$lackbox{1}{f O}$ how to order parts from the remington factory

TO ORDER PARTS

- 1. Use the picture on page 15 to find the correct part name and number.
- 2. Write the model and serial number of your firearm, and the part name and number on the parts order.
- 3. Send parts order to:

Arms Service Division Remington Arms Company, Inc. Ilian, New York 13357

1. We can ship your order on a C.O.D. basis or provide an estimate of your required remittance.

NOTE: Bolts, berrels or receivers for centerfire rifles, pistols and rimfire rifles are not sold separately Repairs or replacements for these parts must be done by Remington Arms Company, Inc. Barrels and boits for shorguns are available as parts.

WARNING: Use only Remington parts in Remington

TO ORDER FACTORY SERVICE:

Write a short description of the problem.

1. Give the model and serial number. Make a copy of this note. Attach the original note to the firearm, and put the copy in an envelope attached to the outside of the shipping box.

- 2. Make sure the gun is unloaded. Never include any ammunition in the package with the firearm.
- Send by either United Parcel Service or Parcel Post. NOTE: Make sure the gun is unloaded, and there is no ammunition in the box.
- Get insurance for the fireerm.
- 5. Record serial number, it is required when calling factory to inquire if firearm has been received for

INSTRUCTION BOOKS:

To get instruction books for any Remington firearm, write to Remington Arms Company, Inc., Arms Service Division, Ilion, New York 13357. Give the model, serial number, gauge or caliber.

REMINGTON RECOMMENDED GUNSMITHS:

A listing is available from Remington Arms Company, Inc., 939 Semum Avenue, Bridgeport, Conn. 06602.