

Inspect 5 Trigger Blocks, EXP10016, per instruction.

Print with highlighted inspection dimensions will be provided to inspector.