

Subject:**Bolt Action Centerfire Update Notice****Notice of Operation: Non-Bolt Lock Centerfire Firearms:**

Due to the changes in the trigger assembly now installed on your firearm, it will no longer be necessary for you to put the safety in the "F" or "Fire" position to load or unload the rifle. Your rifle can be loaded and unloaded while the safety is kept in the "S" or safe position. However, you still need to follow common safety rules while loading or unloading your rifle. Always keep the muzzle of any firearm pointed in a safe direction, especially when you are loading or unloading. Always unload your firearm when not in use. Always unload your firearm as soon as you have finished shooting before taking it into your car, camp or home. For further information on firearms safety visit us at www.remington.com