

TRIGGER PULL WITH TRIGGER RETURN SPRING AND ADJUSTMENT SCREW REMOV
MEASURED WITH SPRING SCALE

	1	2	3	AVG.	
B-13	3.25	2.75	2.5	2.833	6 back to orig. (1.5, 1.75, 1.5)
B-14	2.25	2.75	3	2.667	4 sear(B16), bolt(B16) (2.5, 2.25, 2.25)
B-15	1.75	2	2	1.917	2 w/sear from B-16 (1.5, 1.5, 1.5)
B-16	3.25	3.75	3.75	3.583	1 w/sear from B-15 (2.5, 2, 2.5)
B-17	VERY ROUGH TRIGGER, CAN FEEL & HEAR THE TRIGGER				3 sear(B15), bolt(B15) (2, 2, 2)
B-18	2.5	3.25	3.25	3.000	5 back to orig. (3.5, 3, -3)

Gun (B-15) bolt f(16) (1 3/4, 2 1/4, 2)

Gun 16 bolt 15 (3 1/4, 2 3/4, 2 1/2) 3 1/4

Gun 16 bolt 16 (3 1/4, 2 3/4, 3 1/2)

B-16 w/polished Sear (2 3/4, 2 1/2, 2 3/4)
Matt G

B-16 w/another polished Sear (3, 3, 3 1/4)
Matt G

B-16 Dykum Blue on Sear (2, 2 1/2, 2 1/2) shows localized contact on sear

B-16 orig. sear w/oil (2 3/4, 2 3/4, 4, 3 1/2) (2 1/2, 3, 3)

on trigger 2 1/2, 2 3/4, 2 1/2

bracket
Screw
loose

ET27977