

why can't I engage the safety mechanism towards the "S" position without rais...

Discussion Thread

Response (Laura)

At 01/29/2002 01:31 PM we wrote -

Dear Sir,

Thank you for your interest in our firearms. However we cannot sell any firearms direct to you. You will need to go through one of the following distributors for assistance:

HELMUT HOFMANN, GmbH
SCHEINBERGWEG 6-8, POST FACH 60
97638 MELLRICHSTADT
helmuthofmann@t-online.de
011 49 9776 6060
011 49 9776 60621

HORST TRIGATTI, GmbH
VEITSHOCHHEIMER STR. 3
D-97080 WURZBURG
011 49 931 18176
011 49 931 59659

Customer (Lorand Reich)

----- 01/26/2002 05:13 AM -----

why can't I engage the safety mechanism towards the "S" position without raising the bolt handle prior to loading?

The Owner's Manual (p.7) clearly states that one should "Always put the safety mechanism in the "S" position before handling, loading or unloading the firearm".