

<http://www.remington.com/repairsvc/modelselection.asp>

To view the warranty for Remington firearms, go to:

<http://www.remington.com/support/warranty.htm>

Customer (Brian Henderson) 11/19/2003 8:32:19 PM
I have a Model 700 (serial number S6223196) which sometimes will not cock on opening. Even when opened and fully cycled with a new round, the firing pin does not stay cocked. It will eventually, but it sometimes takes several cycles of the bolt. The result is that the firing pin is not held all the way back and I am concerned that if not fully cocked it will result in a accidental discharge if the uncocked bolt is closed on a live round. Please let me know what I should do or if there was any kind of recall regarding this problem with this firearm.

Brian Henderson
P.O. Box 70
Stigler, OK 74462
(918) 967-8002