

configuration and safety

Discussion Thread

Response (Jessica)

2/8/2005 2:37:01 PM

Dear Saint,

Thank you for your inquiry. The sear and trigger configuration is set at the factory using an optical comparator and specification layouts. Once the proper engagement, trigger pull, and over-travel have been set the adjustment screws are sealed. Properly set the sear and trigger configuration provide a safe firearm.

Customer (saint rh1)

2/6/2005 11:28:22 AM

I want to know the configuration of the sear and trigger in remington700 model rifle, and also want to know how this configuration can be safe.