


TO REMOVE THE MAGAZINE:

1. Point the firearm in a safe direction.
2. Engage the safety mechanism. **RED BAND WILL NOT SHOW.**
3. **CAUTION:** Keep your fingers away from the ejection port and operating handle.
4. Push the bolt release to close the action. See Picture 8.
5. Push the magazine latch forward. See Picture 7. Pull the magazine from the receiver.



PICTURE 7


The Trigger Assembly

Putting the trigger fits the firearm.

The weight of the trigger pull is preset at the factory.

All adjustments to the trigger and trigger plate assembly must be made by the factory or a REMINGTON® AUTHORIZED GUNSMITH.

WARNING: NEVER put your finger on the trigger unless you are going to fire the firearm.



PICTURE 8

The Barrel

The inside of the barrel must be clean and free of obstructions.

I. TO CHECK THE INSIDE OF THE BARREL:

WARNING: Look into the ejection port. Check the chamber and magazine for live rounds before looking into the barrel.

1. Point the firearm in a safe direction.
2. Engage the safety mechanism. Make sure the **RED BAND IS NOT SHOWING.**
3. Pull the operating handle fully rearward until the bolt is no longer obstructed by the magazine follower.
4. Insert a cleaning rod into the muzzle. Push the rod to insert it through the barrel until the rod can be seen in the ejection port.

II. TO REMOVE OBJECT FROM INSIDE THE BARREL:

WARNING: Never try to remove an object from the barrel by pulling the action and firing. This may cause the barrel to burst or a cartridge case to rupture and result in personal injury.

1. Use the correct size cleaning rod.
2. Insert the cleaning rod into the muzzle and gently tap rod to free object.
3. Push the cleaning rod all the way through the barrel until the rod can be seen in the ejection port.
4. If an object cannot be easily pushed out of the barrel with a cleaning rod, return the firearm to the factory or a REMINGTON RECOMMENDED GUNSMITH.

III. TO CLEAN THE BARREL FOLLOW THE INSTRUCTIONS SHOWN ON PAGE 11.

BEFORE LOADING THE FIREARM: Make sure the inside of the barrel is free of dirt or other objects.