



## Remington® Model 7600™ Pump Action Centerfire Rifle

*Congratulations on your choice of a Remington®. With proper care, it should give you many years of dependable use and enjoyment. For best results, we recommend that you use Remington Ammunition—the ammunition used in factory testing your firearm against our exacting function and performance standards.*

PICTURE 1 This picture shows the main parts of a REMINGTON MODEL 7600™ PUMP ACTION Rifle. The picture will aid in understanding the instructions in this book.



PICTURE 2 This picture shows the parts of the cartridge.



## Important Parts of the Firearm

### The Safety Mechanism

The safety mechanism on the Model 7600™ Centerfire Rifle is a button located behind the trigger. See Pictures 3 and 4.

The safety mechanism provides protection against accidental or intentional discharge under normal usage when properly engaged and locked in working order.

To engage the safety mechanism, push the button so the **RED BAND MARKING CANNOT BE SEEN**.

Always engage the safety mechanism when the firearm is loaded and you do not intend to shoot.

Never pull the trigger when the safety mechanism is engaged.

When you are ready to fire the firearm, press the safety mechanism so that the **RED BAND MARKING IS SHOWING**.

Do not touch the trigger while moving the safety mechanism. Your fingers and all other objects should be kept outside of the trigger guard and away from the trigger until you are actually ready to fire by pulling the trigger.

**WARNING:** The firearm will fire after the trigger is pulled if the **RED BAND IS SHOWING**.

Even when the safety mechanism is engaged, careless handling can cause the firearm to fire. See the *Ten Commandments of Firearm Safety* on page 2.

