

TO CLEAN THE TRIGGER PLATE ASSEMBLY:

WARNING: Make sure there are no cartridges in the magazine or chamber.

1. Engage the safety mechanism. **RED BAND WILL NOT SHOW.**
2. Close the action.
3. Tap out front and rear trigger plate pins.
4. Lift rear of the trigger plate assembly and remove the assembly from the receiver. See Picture 13.




NOTE: Clean trigger plate assembly as a unit with Rem™ Oil.

5. Spray the trigger plate assembly with Rem™ Oil as shown. See Picture 14. Let stand for 15 minutes. Spray again to wash off components. Shake off excess lubricant.

WARNING: Excessive use of a high-volume aerosol lubricant can adversely affect the function and safe operation of your firearm.

6. Check to make sure that the end of the disconnect is below end of trigger connector. See Picture 15.
7. Carefully insert the trigger plate assembly into the receiver.
8. Position to align holes and tap in front and rear trigger plate pins.

WARNING: This firearm should be checked periodically by an Remington Arms Company, Inc. or an Authorized Remington Gunsmith. This will ensure proper inspection and any necessary replacement of damaged parts.



How to Obtain Parts and Service From Remington.

TO ORDER PARTS:

Many Remington Dealers and Authorized Repair Centers carry a full line of parts. Please check with them first before ordering parts.

To expedite your PARTS order or request INFORMATION, visit our web site at: www.remington.com. Detailed instructions are provided along with parts and/or service order forms. You may also reach Remington by calling our toll free customer service number, 1-800-243-9700, Mon. - Fri., 9:00 AM-5:00 PM Eastern time.

1. Fax completed order form (from the web site) to 1-800-448-7801.
2. To order by phone without the order form call 1-800-243-9700.

Please have the following information ready before you call:

- Firearm model and serial number.
- Part description and quantity. Part descriptions can be found on the parts listing page in this manual.
- Your complete mailing address (P.O. Box and Street address) including zip code, telephone number and e-mail address.
- Method of payment: MasterCard, Visa, American Express card number and expiration date. Prepayment may be made by check or money order. A quote may be made to you over the phone. (Sorry, no C.O.D.s.)

WARNING: USE ONLY REMINGTON PARTS IN REMINGTON FIREARMS.

NOTE: SOME PARTS MAY BE RESTRICTED. See page 10 for details. Owner's manual/instruction books may be requested via our web site at www.remington.com or by calling 1-800-243-9700.