

MODEL 700™ **Bolt Action Centerfire Rifle** **PARTS LIST**

VIEW #	PART NAME	VIEW #	PART NAME
1	Barrel Assembly	30	Magazine, ADL Grade
2	Bolt Assembly		Magazine, BDL Grade (Not Shown)
3	Bolt Plug	31	Magazine Follower, ADL Grade
4	Bolt Stop (Restricted)		Magazine Follower, BDL
5	Bolt Stop Pin (Restricted)		Magazine Tail Screw, ADL Grade
6	Bolt Stop Spring (Restricted)	32	Magazine Spring, ADL Grade
7	Butt Plate		Magazine Spring, BDL Grade
	Butt Plate Frame (New Style Not Shown)	33	Main Spring
	Butt Plate Insert (New Style Not Shown)	34	Rear Sight Screw
	Butt Plate Frame Screw (New Style)	35	Rear Sight Aperture
8	Butt Plate Spacer		Rear Sight Assembly
9	Butt Plate Screw		Rear Sight Base
10	Carrier Guard Screw, ADL Grade	37	Rear Sight Base Screw (2)
11	Ejector	38	Rear Sight Slide
12	Ejector Pin	39	Elevation Screw
13	Ejector Spring	40	Rear Sight Screw
14	Extractor	41	Receiver Plug Screw
15	Firing Pin Assembly	42	Seal Pin (New Style)
16	Firing Pin Cross Pin	43	Stock Assembly, ADL Grade
17	Floor Plate Latch, BDL Grade		Stock Assembly, BDL Grade
18	Floor Plate Latch Pin, BDL Grade		Stock Reinforcing Screw (Not Shown)
19	Floor Plate Latch Spring, BDL Grade		Stock Reinforcing Screw Dowel (Not Shown)
20	Floor Plate Pivot Pin, BDL Grade	44	Trigger Assembly (Restricted)
21	Front Guard Screw	45	Trigger Guard
22	Front Guard Screw Bushing, ADL Grade	46	Trigger Guard Assembly, BDL Grade
23	Front Sight	47	Windage Screw
24	Front Sight (Low)		
25	Front Sight Ramp, BDL		
26	Front Sight Ramp Screw		
27	Front Sight Hood		
28	Front Swivel Screw		
29	Grip Cap, BDL Grade (Not Shown)		
	Grip Cap Screw		
	Grip Cap Spacer (Not Shown)		