

Model 700 Trigger Assembly

Hooked on the tang, (back where trigger connected) of the receiver

Trigger sear holds the firing pin back when in the cocked position

Safety will block the sear and trigger

Safety – back position / forward position, off safety

Safety will make a clicking sound

Lack of maintenance can cause accidental discharge (Accidental discharge from lack of maintenance or alterations done to firearm.

Hole in bbl behind the recoil lug. Pressure release valve – Added safety feature (made for hand loaders to help deter blown bbl and receivers)

Lands and Grooves

Lands and Grooves stop just before the projectile. Free Bore or Throat of BBL. – this is a safety feature.

Throat is eroded and want a new gun. – send to factory for inspection.