

## Instructions for Bolt Disassembly Without Using Bolt Disassembly Tool (See Diagram Below):

Place firearm on safe, and be sure it is infloaded! Remove the bolt assembly. (Per instructions in your owner's manual or directions above). Put the notch on the firing pin head over a metal edge. Pull the bolt assembly away from the firing pin. Put a coin (dime) into the slot near the back edge of the firing pin head. Hold the bolt assembly and turn the bolt plug counter clockwise until the firing pin assembly can be removed from the bolt assembly. Do not remove coin from firing pin assembly.

5