

## CLEANING THE BARREL

### Bore Cleaning Instructions

**Place firearm in the safe position, and be sure that it is unloaded!**

1. Remove bolt from the rifle according to the owner's manual.
2. Assemble the rifle cleaning rods by screwing the three pieces together, being careful not to over-tighten.
3. Insert bore guide into receiver if you have one (optional).
4. Screw rifle patch puller on to the end of the cleaning rod, and insert a cotton patch (caliber specific) through the slot. **Note:** Patch pullers are caliber specific. Be sure to use the one made for the caliber of your rifle. Place a small amount of **Remington Bore Cleaner** on the patch.
5. Insert the cleaning rod through the rear of the receiver, and into the bore (from the breech end). **Note:** be careful not to scratch the outside edges of the bore (barrel). Push the patch through the bore, and out the muzzle end of the barrel. Remove patch and pull the cleaning rod out of the barrel.
6. Next, take the patch holder off of the cleaning rod, and screw on the bronze bore brush (caliber specific). Insert the cleaning rod with the bore brush back through the receiver, and into the bore. Push the brush back and forth in the bore of the barrel five to ten times. Remove the cleaning rod from the bore.
7. Remove bore brush from the cleaning rod, and insert the cleaning jag (caliber specific) into the end of the cleaning rod. Place a small amount of **Remington Bore Cleaner** on a cotton patch, and push the patch through the bore using the cleaning rod and jag. Push the patch out through the muzzle of the bore, and remove. Pull the cleaning rod out of the bore and repeat the process with a cleaning patch soaked with Brite Bore. Pull the cleaning rod out of the bore, and repeat the process, with dry cotton patches until the bore is clean, and free from residues.
8. Clean the chamber area using larger or several patches. You can also use a chamber brush if available.
9. Add a light coat of **Rem Oil** to the bore, using the cleaning rod, jag, and a cotton patch. **Note:** Clean all oil from the bore before firing the firearm.
10. Apply a thin coat of Rem Oil to the outside of the barrel with a soft, clean cloth.

## CLEANING THE RECEIVER AND TRIGGER ASSEMBLY

### Receiver Cleaning Instructions

**\*\*There are three types of Model 700 rifles: one without a FLOOR PLATE (Model 700 ADL), one with a FLOOR PLATE (Model 700 BDL), and one with a DETACHABLE MAGAZINE BOX (Model 700 BDL DM).**

Before the receiver can be properly cleaned, the stock must be removed from the firearm. To do this, remove all the guard screws. (2 for BDL and BDL DM; 3 for ADL) Depending on the date of manufacture the trigger guard screws will either be flat head or allen head. In the case of flat head screws they can be removed with a medium size flat head screw driver. In the case of allen head screws the front and rear screws will require a 5/32 inch allen wrench (all models). For ADL's the