

CLEANING THE STOCK ASSEMBLY

Stock Assembly Cleaning Instructions:

Wood or Wood Laminate Stocks:

The wooden stock on your Model 700 is made of high quality American Walnut. To keep the stock looking new, wipe down after use with a clean rag. Clean all dirt and debris from the inside, as well. A small amount of **Rem-Oil** can be applied.

Synthetic Stocks:

Model 700 synthetic stocks are very durable, and require little maintenance. Wipe away all dirt and debris from inside and outside of stock. No oil is necessary. You can use mild soap and water if necessary. Dry it off with a clean, soft cloth. **Do not use any type of solvent on synthetic stocks.** Powder solvents can harm the synthetic material.

SHOULD YOUR STOCK BECOME RAIN-SOAKED: wipe with clean cloth immediately and make sure it is totally "air dried" before reassembly of your firearm and/or storing your firearm. A few drops of Rem Oil rubbed onto your stock with a clean lint free cloth will remove any dust or dirt.

MODEL 700 RE-ASSEMBLY INSTRUCTIONS

Once you have properly cleaned your Model 700, re-assembly is required. Before assembly, a light coat of **Rem-Oil** may be applied to all exterior metal components. This will inhibit rust during long term storage.

1. To assemble, place the barrel and action into stock.
2. Turn firearm upside down, and install the trigger guard assembly (BDL and DM models). For BDL models with a hinged floor plate, the magazine spring and follower (attached to trigger guard assembly) will need to be inserted first. Hold the trigger guard assembly into place, and install front and rear trigger guard screws. For ADL models, install the magazine spring and magazine spring follower into the stock, place the barrel and action into the stock and then turn stock upside down. Hand tighten the screws. **Caution:** do not over tighten the trigger guard screws. This can cause damage to the stock.
3. For BDL models, close floor plate, for BDL-DM models insert the detachable magazine.
4. Once the stock and trigger guard assembly have been installed, **be sure that the firearm is unloaded and in the safe position**, and re-install the bolt assembly. To install the bolt, align the front of the bolt with the back action, and gently push forward. **Note:** If the bolt is assembled incorrectly, it can not be re-installed. Refer to the section on Bolt Re-Assembly.

****Please note:** If you have any questions or concerns during the cleaning, disassembly or re-assembly process, please contact our Parts and Repair Department at 1-800-243-9700 Mon-Fri 9a.m. -5 p.m. EST.