CONFIDENTIAL

Remington Arms Company Inc. RESEARCH & DEVELOPMENT TECHNICAL CENTER 315 WEST RING ROAD

- Remove the rifle from the small snail bullet trap.
- Using the plug gauges measure the minimum clearance between the rear of the trigger and the inside rear of the trigger guard.
- Re-measure the trigger pull, engagement and over-travel to insure that they have not changed from the beginning of the test.

Data required:

- Rifle serial number
- Measurements of Trigger pull, engagement, over-travel and trigger/trigger guard clearance before and after loading.
- Note that the rifle "fired" or did not fire when the safety was pushed to the "Fire" position.
- Note that the rifle did "fire" when the trigger was pulled

J.R.Snedeker TLW 0683

Page 23 of 50 Remington Confidential 05/24/06

Revision # 1.3