

AMMO TYPES				LOTS			
MALFUNCTIONS				MALFUNCTIONS			
1	1	REM PRA300WC	LOT 429IB1	21	1	REM PRC300WC	LOT S16 RCI
2	2			22	2		
3	3			23	3		
4	4			24	4		
5	5			25	5		
6	6			26	6		
7	7			27	7		
8	8			28	8		
9	9			29	9		
10	10			30	10		
11	11			31	11		
12	12			32	12		
13	13			33	13		
14	14			34	14		
15	15			35	15		
16	16			36	16		
17	17			37	17		
18	18			38	18		
19	19			39	19		
20	20	No screw movement		40	20	No screw movement	
		REM PRSC300WB	LOT T25B31			REM R300W2	LOT 416 NR1
MALFUNCTIONS				MALFUNCTIONS			
1	1			21	1		
2	2			22	2		
3	3			23	3		
4	4			24	4		
5	5			25	5		
6	6			26	6		
7	7			27	7		
8	8			28	8		
9	9			29	9		
10	10			30	10		
11	11			31	11		
12	12			32	12		
13	13			33	13		
14	14			34	14		
15	15			35	15		
16	16			36	16		
17	17			37	17		
18	18			38	18		
19	19			39	19		
20	20	No screw movement		40	20	No screw movement	
		REM R300W1	LOT G26A C0623			REM RS300WA	LOT R15E B0023
MALFUNCTIONS				MALFUNCTIONS			
1	1			21	1		
2	2			22	2		
3	3			23	3		
4	4			24	4		
5	5			25	5		
6	6			26	6		
7	7			27	7		
8	8			28	8		
9	9			29	9		
10	10			30	10		
11	11			31	11		
12	12	mag BOX began to push out		32	12		
13	13			33	13		
14	14			34	14		
15	15			35	15		
16	16			36	16		
17	17			37	17		
18	18			38	18		
19	19			39	19		
20	20	No screw movement		40	20	No screw movement	

AMMO TYPES			LOTS		
MALFUNCTIONS			MALFUNCTIONS		
1	1	WIN SHV300WM2 LOT <i>R202</i>	21	1	FED P300WC LOT <i>204 J030</i>
2	2		22	2	
3	3		23	3	
4	4		24	4	
5	5		25	5	
6	6		26	6	
7	7		27	7	
8	8		28	8	
9	9		29	9	
10	10		30	10	
11	11		31	11	
12	12		32	12	
13	13		33	13	
14	14		34	14	
15	15		35	15	
16	16		36	16	
17	17		37	17	
18	18		38	18	
19	19		39	19	
20	20	<i>no screw movement</i> WIN X30WM2 LOT <i>914M42</i>	40	20	<i>middle screw same movement</i>
MALFUNCTIONS			MALFUNCTIONS		
1	1		21	1	
2	2		22	2	
3	3		23	3	
4	4		24	4	
5	5		25	5	
6	6		26	6	
7	7		27	7	
8	8		28	8	
9	9		29	9	
10	10		30	10	
11	11		31	11	
12	12		32	12	
13	13		33	13	
14	14		34	14	
15	15		35	15	
16	16		36	16	
17	17		37	17	
18	18		38	18	
19	19		39	19	
20	20	<i>No screw movement</i> FED 300WGS LOT <i>304 J153</i>	40	20	<i>No screw movement</i>
MALFUNCTIONS			MALFUNCTIONS		
1	1		21	1	
2	2		22	2	
3	3		23	3	
4	4		24	4	
5	5		25	5	
6	6		26	6	
7	7		27	7	
8	8		28	8	
9	9		29	9	
10	10		30	10	
11	11		31	11	
12	12		32	12	
13	13		33	13	
14	14		34	14	
15	15		35	15	
16	16		36	16	
17	17		37	17	
18	18		38	18	
19	19		39	19	
20	20	<i>No screw movement</i>	40	20	

83