

CONFIDENTIAL

Remington Arms Company Inc.
Research & Development Technical Center
315 West Ring Road
Elizabethtown, KY 42701

- Move the crusher holder so that the point of the dial indicator finds the deepest portion of the firing pin indent.
- Record the dial indicator reading to the nearest .001”.
- Repeat procedure two more times and record the dial indicator readings using a new copper crusher for each trial.
- Each firearm sample should have three readings that will be averaged.
- Record all three readings for the data file.

Data Required:

- Rifle serial number
- Each of the three trial indents
- The calculated average indent by rifle.

TLW0300I - Measure Sear/Trigger Engagement and Sear Lift:

The Sear/Trigger Engagement will be measured. The amount of engagement must be measured between .020” and .025” measured with the bolt in the fully closed and locked position.

Method for measuring Sear/Trigger Engagement:

- The 30” Optical comparator will be used to measure the engagement at 50X magnification.
- With the barreled action held firmly in position, the barreled action will be aligned such that the action is held perpendicular to the lens in both the horizontal and vertical planes.
- With action closed and locked, the safety in the “fire” position, measure the amount of overlap between the sear and the trigger.

Method for measuring Sear Lift:

- Remove the bolt from the action.
- Place the Safety in the “Off-Safe” (i.e. “Fire”) position.

J.R.Snedeker

Page 13 of 51

5:25 PM

11/02/00

TLW0300

Remington Confidential

Revision # 3

ET53514