

CONFIDENTIAL

Remington Arms Company Inc.
RESEARCH & DEVELOPMENT TECHNICAL CENTER
315 WEST RING ROAD
ELIZABETHTOWN, KY 42701

After every 100 rounds one live round will be extracted and ejected from the chamber to check on live round ejection. The ejected round will then be re-inserted into the chamber and fired to help keep the endurance round count accurate.

Method:

- Disassemble, thoroughly clean, lubricate per the design team's instructions, and re-assemble. Record headspace for each.
- Fire each test firearm in accordance with the firing procedure (number of rounds, firing cycle) specified by engineering and the test plan.
- Ammunition will be used that comprises at least five types of bullets, change ammunition type every 100 rounds.
- Before commencing design acceptance testing, calibrate, adjust, or re-build the shooting jacks, if necessary.
- Allow the firearm to completely recover in the shooting jack between each shot and do not lean or "stiff arm" the firearm while shooting the gun.
- All ammunition is to be functioned through the magazine - no "single shot" hand feeding permitted.
- Allow the rifle to cool between cycles. One cycle is 20 rounds fired. The use of forced air to accelerate cooling of the barrels between firing trials is permitted. The air should be directed from the chamber toward the muzzle to prevent it from washing the lubricant from the firearm's action.
- Cycle the safety from fire to safe every 5 rounds, from Safe to Fire at the start of the five round cycle and from Fire to Safe at the end of the 5 round cycle.
- After 400 rounds, disassemble, inspect, clean and lubricate the entire mechanism and take all required measurements.
- The Standard Remington Jacks (using the heavy configuration) are to be used for this test.

Data Required:

- Rifle serial number
- Tester's name
- The Test Jack Identification

J.R.Snedeker

Page 26 of 32

9:47 AM

05/24/06

TLW0407

Remington Confidential

Revision # 2