

CONFIDENTIAL

Remington Arms Company Inc.
RESEARCH & DEVELOPMENT TECHNICAL CENTER
315 WEST RING ROAD
ELIZABETHTOWN, KY 42701

- Turn the firearm to its normal upright horizontal position and apply a tablespoon of sand and dust to the top of the firecontrol mechanism from the top. Tap the firearm three times, in the middle of the receiver, to jar the rifle and aid sand getting into the mechanism.
- Replace the bolt. Wipe away any sand that prevents the bolt from closing.
- Load the magazine. Fire a full magazine from the firearm. If there are repeated malfunctions, attempt to fire with another magazine. If firing is still unsatisfactory, attempt to fire with a clean magazine, container, etc., loaded with clean ammunition. If repeated malfunctions make it impractical to fire the remaining ammunition (from a box of 20 cartridges), stop the test.
- At every 5 round interval verify the firearm is not loaded.
- Close the firearm as if to fire it and put the safety to the SAFE position.
- Pull the trigger firmly (10 lb. maximum) - firearm must not fire.
- With the finger off the trigger, move the safety to the FIRE position - firearm must not fire.
- Carefully disassemble the firearm over large sheet of white paper and weigh the amount of debris that finds its way into the main mechanism area.

J.R. Snedeker

Page 47 of 62

03/31/00

Remington Confidential

Revision #2

Subject to Protective Order - Williams v. Remington

BARBER - 5.30.06R0003089

ETE00003088